

WEL-TRY®
為彩®

WEL-TRY ciss/refillable/compatible/chip catalogue

中国为彩实业有限公司产品目录

WEL-TRY for Epson IX Series Inkjet Cartridge 爱普生第九代产品

Product Codex型号	OEM Product 原装型号Code	Region /地区	Description适用打印机
WEL-TRY-T10JBK/T10JC/T10JM/T10JY	T10JBK/T10JC/T10JM/T10JY	KOR/HK 韩国 /香港	Epson XP-2200/XP-4200/WF-2950
WEL-TRY-T09S1/T09S2/T09S3/T09S4/T09U1	T09S1/T09S2/T09S3/T09S4/T09U1	HK 香港	Epson WorkForce WF-2960
连供图片/ciss		填充图片/refillable	兼容成品compatible



WEL-TRY-IP11KA/IP11CA/IP11MA/IP11YA	IP11KA/IP11CA/IP11MA/IP11YA	JPN/日本	Epson PX-S887/PX-M887F
WEL-TRY-IP11KB/IP11CB/IP11MB/IP11YB	IP11KB/IP11CB/IP11MB/IP11YB	JPN/日本	
WEL-TRY-T11G1/T11F2/T11F3/T11F4	T11G1/T11F2/T11F3/T11F4	HK/香港	Epson WorkForce Pro WF-C5890/WF-C5390
连供图片/ciss		填充图片/refillable	兼容成品compatible



WEL-TRY for Epson VIII Series Inkjet Cartridge 爱普生第八代产品

Product Codex型号	OEM Product 原装型号Code	Region /地区	Description适用打印机
WEL-TRY-603BK/603C/603M/603Y	603BK/603C/603M/603Y	EUR/欧洲	Epson Expression Home XP-2100/XP-2105/XP-3100/XP-3105/XP-4100/XP-4105 Epson WorkForce WF-2810/WF-2830/WF-2835/WF-2850
WEL-TRY-603XLBK/603XLC/603XLM/603XLY (WEL-TRY-603XLBK/603XLCY/603XLMG/603XLYL)	T03A1(603XLBK)/T03A2(603XLC)/T03A3(603XLM)/T03A4(603XLY)	EUR/欧洲	
WEL-TRY-502BK/502C/502M/502Y	502BK/502C/502M/502Y	EUR/欧洲	Epson Expression Home XP-5100/XP-5105 Epson WorkForce WF-2860DWF/WF-2865DWF
WEL-TRY-502XLBK/502XLC/502XLM/502XLY	T02W1(502XLBK)/T02W2(502XLC)/T02W3(502XLM)/T02W4(502XLY)	EUR/欧洲	
WEL-TRY-NA202XLBK/NA202XLC/NA202XLM/NA202XLY	T202XL1(T02P1)/T202XL2(T02P2)/T202XL3(T02P3)/T202XL4(T02P4)	NA/AUS北美/澳洲	Epson Expression Home XP-5100 Epson WorkForce WF-2860
WEL-TRY-MUGBK/MUGC/MUGM/MUGY	MUGBK/MUGC/MUGM/MUGY	JPN/日本	Epson EW-052A/EW-452A
WEL-TRY-IB10KA/IB10CA/IB10MA/IB10YA	IB10KA/IB10CA/IB10MA/IB10YA	JPN/日本	Epson EW-M530F
WEL-TRY-04EBK/04EC/04EM/04EY	T04E1/T04E2/T04E3/T04E4	HK/香港	Epson Expression Home XP-2101/XP-4101 Epson WorkForce WF-2831/WF-2851
WEL-TRY-03CBK/03CC/03CM/03CY	T03C1/T03C2/T03C3/T03C4	HK/KOR/香港/韩国	Epson WorkForce WF-2861
WEL-TRY-03DBK/03DC/03DM/03DY	T03D1/T03D2/T03D3/T03D4		
WEL-TRY-206BK/206C/206M/206Y	T2061/T2062/T2063/T2064	LA/拉丁美洲	Epson Expression XP-2101
WEL-TRY-39XLBK/39XLC/39XLM/39XLY	T04L1(39XLBK)/T04L2(39XLC)/T04L3(39XLM)/T04L4(39XLY)	AUS/澳洲	Epson Expression Home XP-2105/XP-4105
WEL-TRY-212XLBK/212XLC/212XLM/212XLY	T02X1(212XLBK)/T02X2(212XLC)/T02X3(212XLM)/T02X4(212XLY)	AUS/澳洲	Epson Expression Home XP-2100/XP-4100 Epson WorkForce WF-2810/WF-2830/WF-2850

连供图片/ciss

填充图片/refillable

兼容成品图片
compatible



WEL-TRY-405XXLBK/405XLC/405XLM/405XLY	405XXLBK/405XLC/405XLM/405XLY	EUR/欧洲	Epson WF-7830DTWF/7835DTWF/7840DTWF
WEL-TRY-405BK/405C/405M/405Y	405BK/405C/405M/405Y	EUR/欧洲	Epson WF-3820DWF/WF-3825DWF/WF-4820DWF/WF-4825DWF/WF-4830DTWF/ WF-7830DTWF/WF-7835DTWF/WF-7840DTWF
WEL-TRY-405XLBK/405XLC/405XLM/405XLY	405XLBK/405XLC/405XLM/405XLY	EUR/欧洲	Epson WF-4830DTWF/WF-4820DWF/WF-3820DWF/WF-7830DTWF/ WF-7835DTWF/WF-7840DTWF
WEL-TRY-812XXLBK/812XLC/812XLM/812XLY	812XXLBK/812XLC/812XLM/812XLY	NA/AUS北美/澳洲	Epson WorkForce WF-7840/WF-7845/WF-7830/WF-7840/WF-7820/EC-C7000
WEL-TRY-812XLBK/812XLC/812XLM/812XLY	812XLBK/812XLC/812XLM/812XLY	NA/AUS北美/澳洲	Epson WF-3820/WF-3825/WF-4830/WF-4835/WF-7840/WF-7820/EC-C7000
WEL-TRY-822XLBK/822XLC/822XLM/822XLY	822XLBK/822XLC/822XLM/822XLY	NA/AUS北美/澳洲	Epson WF-3820/WF-4820/WF-4830/WF-4834
WEL-TRY-IB07KA/IB07CA/IB07MA/IB07YA	IB07KA/IB07CA/IB07MA/IB07YA	JPN/日本	Epson PX-M6011F/M6010F/S6010 New !
WEL-TRY-IB07KB/IB07CB/IB07MB/IB07YB	IB07KB/IB07CB/IB07MB/IB07YB		
WEL-TRY-IB09KB/IB09CB/IB09MB/IB09YB	IB09KB/IB09CB/IB09MB/IB09YB	JPN/日本	Epson PX-M730F
WEL-TRY-T05NBK/T05NC/T05NM/T05NY	T05NBK/T05NC/T05NM/T05NY	HK/香港	Epson WorkForce WF-7841
WEL-TRY-T05UBK/T05UC/T05UM/T05UY	T05U1/T05U2/T05U3/T05U4	CHN/中国	Epson WorkForce WF-4838
WEL-TRY-T05NBK/T05UC/T05UM/T05UY	T05NBK/T05U2/T05U3/T05U4	CHN/中国	Epson WorkForce WF-7848
WEL-TRY-T924XLBK/T924XLC/T924XLM/T924XLY	T924XLBK/T924XLC/T924XLM/T924XLY	NA/北美	Epson WorkForce Pro WF-C4810 Color MFP
WEL-TRY-408LBK/408LC/408LM/408LY	408LBK/408LC/408LM/408LY	EUR/欧洲	Epson WorkForce Pro WF-C4810DTWF
WEL-TRY-408BK/408C/408M/408Y	408BK/408C/408M/408Y	EUR/欧洲	

连供图片/ciss

填充图片/refillable

兼容成品compatible



WEL-TRY-IB06KA*2/IB06CA/IB06MA/IB06YA	IB06KA*2/IB06CA/IB06MA/IB06YA	JPN/日本	Epson PX-S5010
---------------------------------------	-------------------------------	--------	----------------

连供图片/ciss

填充图片/refillable

兼容成品compatible



WEL-TRY-T05ABK/T05AC/T05AM/T05AY	T05ABK/T05AC/T05AM/T05AY	AUS/澳洲	Epson WorkForce Pro WF-C878R Epson WorkForce Pro WF-C879R
----------------------------------	--------------------------	--------	---

填充墨盒/refillable ink pad

填充墨盒/refillable

兼容墨袋compatible



WEL-TRY-04BBK/04BC/04BM/04BY	T04B1/T04B2/T04B3/T04B4	EUR/欧洲	Epson WorkForce Pro WF-C8190/WF-C8690/WF-C8610
WEL-TRY-04ABK/04AC/04AM/04AY	T04A1/T04A2/T04A3/T04A4	EUR/欧洲	Epson WorkForce Pro WF-C8190/WF-C8690
WEL-TRY-IB02KA/IB02CA/IB02MA/IB02YA	IB02KA/IB02CA/IB02MA/IB02YA	JPN/日本	Epson PX-S7110 Epson PX-M7110F
WEL-TRY-IB02KB/IB02CB/IB02MB/IB02YB	IB02KB/IB02CB/IB02MB/IB02YB		
WEL-TRY-01BBK/01BC/01BM/01BY	T01B1/T01B2/T01B3/T01B4	CHN/中国	Epson WF-C8190a/WF-C8690a

连供/ciss

填充墨盒/refillable

兼容墨袋compatible



WEL-TRY-43UBK/43UC/43UM/43UY/43ULC/43ULM	T43U1/T43U2/T43U3/T43U4/T43U5/T43U6	EUR/欧洲	Epson SureLab SL-D800
--	-------------------------------------	--------	-----------------------

WEL-TRY-43WBK/43WC/43WM/43WY/43WLC/43WLM	T43W1/T43W2/T43W3/T43W4/T43W5/T43W6	CHN/中国	Epson SureLab SL-D880
填充墨盒/refillable		兼容墨袋compatible	



WEL-TRY-T46SY/T46SV	T46SY/T46SV	EUR/欧洲	Epson SureColor SC-P700
WEL-TRY-T46H2/T46H3/T46H4/T46H8	T46H2/T46H3/T46H4/T46H8	AP/亚太地区	Epson SC-F6330
WEL-TRY-ICBK96/ICC96/ICVM96/ICY96/ICLC96/ICVLM96/ICGY96/ICMB96/ICLGY96/ICDBL96	ICBK96/ICC96/ICVM96/ICY96/ICLC96/ICVLM96/ICGY96/ICMB96/ICLGY96/ICDBL96	JPN/日本	Epson SC-PX1VL
WEL-TRY-ICBK97/ICC97/ICVM97/ICY97/ICLC97/ICVLM97/ICGY97/ICMB97/ICLGY97/ICDBL97	ICBK97/ICC97/ICVM97/ICY97/ICLC97/ICVLM97/ICGY97/ICMB97/ICLGY97/ICDBL97	JPN/日本	Epson SC-PX1V

填充墨盒/refillable



WEL-TRY-SJIC36PBK/SJIC36PC/SJIC36PM/SJIC36PY	SJIC36PBK/SJIC36PC/SJIC36PM/SJIC36PY	EUR/欧洲	Epson CW-C6000A
--	--------------------------------------	--------	-----------------

兼容/compatibile



WEL-TRY-
SC18BK70/SC18LGY70/SC18GR70/SC18
GY70/SC18C70/SC18LC70/
SC18V70/SC18VLM70/SC18MB70/SC18Y
70/SC18OR70/SC18VM70

SC18BK70/SC18LGY70/S
C18GR70/SC18GY70/SC
18C70/SC18LC70/SC18V
70/SC18VLM70/SC18MB
70/SC18Y70/SC18OR70/
SC18VM70

JPN/日本

Epson SC-P7550/SC-P7550PS
Epson P9550/SC-P9550PS

填充墨盒/refillable

兼容compatible



WEL-TRY-
T46DHDK/T46DBK/T46DC/
T46DM/T46DY

T46D8/T46D1/T
46D2/T46D3/T4
6D4

EUR/欧
洲

Epson SC-F6300/F6360打印机自带连供直接入
墨

WEL-TRY-
T46FBK/T46FC/T46FM/T46
FY/T46FLC/T46FLM

T46F1/T46F2/T4
6F3/T46F4/T46F
5/T46F6

CHN/中
国

Epson SC-F6380
Epson SC-F9480打印机自带连供直接入墨

WEL-TRY for Epson VII Series Inkjet Cartridge为彩爱普生7代系列 产品

Product Codex型号	OEM Product 原装型号Code	Region /地区	Description适用打印机
WEL-TRY-KUIBKL/KUICL/KUIML/KUIYL/KUILCL/KUILML	KUIBKL/KUICL/KUIML/KUIYL/KUILCL/KUILML	JPN/日本	Epson EP-879AW/AB/AR/EP-880AW/AB/AR/AN
WEL-TRY-SORBK/SORC/SORM/SORY/SORR/SORGY	SORBK/SORC/SORM/SORY/SORR/SORGY	JPN/日本	Epson EP-50V
WEL-TRY-KAMBKL/KAMCL/KAMML/KAMYL/KAMLC/L/KAMLML	KAMBKL/KAMCL/KAMML/KAMYL/KAMLC/L/KAMLML	JPN	Epson EP-881AW/AB/AR/AN/EP-882AW/AB/AR
WEL-TRY-202XLBK/202XLPBK/202XLC/202XLM/202XLY	T02G1(202XLBK)/T02H1(202XLPBK)/T02H2(202XLC)/T02H3(202XLM)/T02H4(202XLY)	EUR/HK	Epson Expression premium XP-6000/XP-6005/XP-6001/XP-6100(5色)
WEL-TRY-378BK/378C/378M/378Y/378LC/378LM	378BK/378C/378M/378Y/378LC/378LM	EUR	Epson Expression Photo XP-8500/8505
WEL-TRY-378XLBK/378XLC/378XLM/378XLY/378XLC/378XLLM	T3791 (378XLBK)/T3792 (378XLC)/T3793 (378XLM)/T3794 (378XLY)/T3795 (378XLLC)/T3796 (378XLLM)	EUR	
WEL-TRY-378XLBK/378XLC/378XLM/378XLY/478XLR/478XLY	T3791 (378XLBK)/T3792 (378XLC)/T3793 (378XLM)/T3794 (378XLY)/T04F5(478XLR)/T04F6 (478XLY)	EUR	
WEL-TRY-312XLBK/312XLC/312XLM/312XLY/312XLC/312XLLM	T312XL1(T1831)/T312XL2(T1832)/T312XL3(T1833)/T312XL4(T1834)/T312XL5(T1835)/T312XL6(T1836)	NA/AUS	Epson Expression Photo XP-8500
WEL-TRY-312XLBK/312XLC/312XLM/312XLY/314XLY/314XLR	T312XL1(T1831)/T312XL2(T1832)/T312XL3(T1833)/T312XL4(T1834)/T314XL7(T01M6)/T314XL8(T01M5)	NA/AUS	Epson Expression Photo HD XP-15000
WEL-TRY-302XLBK/302XLPBK/302XLC/302XLM/302XLY	T302XL0(T01X1)/T302XL1(T01Y1)/T302XL2(T01Y2)/T302XL3(T01Y3)/T302XL4(T01Y4)	NA/AUS	Epson Expression premium XP-6000/XP-6100
WEL-TRY-01UBK/01UC/01UM/01UY/01UR/01UGY	T01U1/T01U2/T01U3/T01U4/T01U5/T01U6	CHN	Epson Expression Photo HD XP-15010/15080
连供图片/ciss		填充图片/refillable	
			兼容成品compatible



WEL-TRY-ICBK84/ICC84/ICM84/ICY84	ICBK84/ICC84/ICM84/ICY84	JPN/日本	Epson PX-M780F/PX-M781F
WEL-TRY-35XLBK/35XLC/35XLM/35XLY	T359(35XLBK)1/T3592(35XLC)/T3593(35XLM)/T3594 (35XLY)	EUR/欧洲	Epson WorkForce Pro WF-4740DTWF/4720DW/4725DW
WEL-TRY-407BK/407C/407M/407Y	407BK/407C/407M/407Y	EUR/欧洲	Epson WF-4745DTWF
WEL-TRY-802XLBK/802XLC/802XLM/802XLY	T802XL1(T3561)/T802XL2(T3562)/T802XL3(T3563)/T802XL4(T3564)	NA/AUS北美/欧洲	Epson WorkForce Pro WF-4720/WF-4730/WF-4740/WF-4734 Epson WorkForce Pro EC-4020/EC-4030/EC-4040
WEL-TRY-349BK/349C/349M/349Y	T3491/T3492/T3493/T3494	HK/香港	Epson WorkForce Pro WF-3721

连供图片/ciss	填充图片/refillable	兼容成品compatible
-----------	-----------------	----------------



WEL-TRY-ICBK86/ICC86/ICM86/ICY86	ICBK86/ICC86/ICM86/ICY86	JPN	Epson PX-M680F/填充xp黑色可以用厚填充133到那是要能装xp芯片座
WEL-TRY-34BK/34C/34M/34Y	T3461(34BK)/T3462(34C)/T3463(34M)/T3464 (34Y)	EUR	Epson WorkForce Pro WF-3725DWF/3720DWF/填充xp黑色可以用厚填充133到那是要能装xp芯片座
WEL-TRY-34XLBK/34XLC/34XLM/34XLY	T3471(34XLBK)/T3472(34XLC)/T3473(34XLM)/T3474 (34XLY)	EUR	
WEL-TRY-702XLBK/702XLC/702XLM/702XLY	T702XL1(T3451)/T702XL2(T3452)/T702XL3(T3453)/T702XL4(T3454)	NA/AUS	Epson WorkForce Pro WF-3720 填充xp黑色可以用厚填充133到那是要能装xp芯片座

连供图片/ciss	填充图片/refillable	兼容成品compatible
-----------	-----------------	----------------



WEL-TRY-IP01KA/IP01CA/IP01MA/IP01YA	IP01KA/IP01CA/IP01MA/IP01YA	JPN/日本	Epson PX-S884 Epson PX-M884F
-------------------------------------	-----------------------------	--------	------------------------------




WEL-TRY-IP01KB/IP01CB/IP01MB/IP01YB	IP01KB/IP01CB/IP01MB/IP01YB	JPN/日本	Epson PX-S884 Epson PX-M884F
WEL-TRY-IP03KA	IP03KA	JPN/日本	Epson PX-M380F/PX-S380
WEL-TRY-IP03KB	IP03KB	JPN/日本	
WEL-TRY-IP03KB	IP03KB	JPN/日本	Epson PX-M381FL/PX-S381L
WEL-TRY-IP04KA	IP04KA	JPN/日本	
WEL-TRY-IP05KA/IP05CA/IP05MA/IP05YA	IP05KA/IP05CA/IP05MA/IP05YA	JPN/日本	Epson PX-M886FL
WEL-TRY-944BK/944C/944M/944Y	T9441/T9442/T9443/T9444	EUR/欧洲	Epson WorkForce Pro WF-C5290/C5790 Epson WorkForce Pro WF-C5210/C5710
WEL-TRY-T945BK/T945C/T945M/T945Y	T9451/T9452/T9453/T9454	EUR/欧洲	
WEL-TRY-946BK/945C/945M/945Y	T9461/T9452/T9453/T9454	EUR/欧洲	Epson WorkForce Pro WF-C5290/C5790
WEL-TRY-01CBK/01CC/01CM/01CY	T01C1/T01C2/T01C3/T01C4	EUR/欧洲	Epson Workforce Pro WF-C529RDTW Epson Workforce Pro WF-C579RDTW
WEL-TRY-01DBK/01DC/01DM/01DY	T01D1/T01D2/T01D3/T01D4	EUR/欧洲	
WEL-TRY-964BK	T9641	EUR/欧洲	Epson WorkForce Pro WF-M5299/M5799
WEL-TRY-965BK	T9651	EUR/欧洲	
WEL-TRY-966BK	T9661	EUR/欧洲	
WEL-TRY-902XLBK/902XLC/902XLM/902XLY	T902XL1/T902XL2/T902XL3/T902XL4	NA/北美	Epson WorkForce Pro WF-C5290/C5790 Epson WorkForce Pro WF-C5210/C5710
WEL-TRY-902XXLBK/902XLC/902XLM/902XLY	T902XXL1/T902XXL2/T902XXL3/T902XXL4	NA/北美	Epson WorkForce Pro WF-C5290/C5790
WEL-TRY-948BK/948C/948M/948Y	T9481/T9482/T9483/T9484	CHN/中国	Epson WorkForce Pro WF-C5790a Epson WorkForce Pro WF-C5290a
WEL-TRY-T949BK/T949C/T949M/T949Y	T9491/T9492/T9493/T9494	CHN/中国	
WEL-TRY-T950BK/T949C/T949M/T949Y	T9501/T9492/T9493/T9494	CHN/中国	
WEL-TRY-968BK	T9681	CHN/中国	Epson WF-M5299a/M5799a
WEL-TRY-969BK	T9691	CHN/中国	
WEL-TRY-970BK	T9701	CHN/中国	
WEL-TRY-T957	T957	AUS/澳洲	EPSON WF-M5299/M5799
WEL-TRY-T958	T958	AUS/澳洲	
WEL-TRY-936BK/936C/936M/936Y	T9361/T9362/T9363/T9364	AUS/澳洲	Epson WorkForce Pro WF-C5790 Epson WorkForce Pro WF-C5290
WEL-TRY-937BK/937C/937M/937Y	T9371/T9372/T9373/T9374	AUS/澳洲	
WEL-TRY-938BK/937C/937M/937Y	T9381/T9372/T9373/T9374	AUS/澳洲	
WEL-TRY-AU01CBK/AU01CC/AU01CM/AU01CY	T01C1/T01C2/T01C3/T01C4	AUS/澳洲	Epson Workforce Pro WF-C529R Epson Workforce Pro WF-C579R
WEL-TRY-AU01DBK/AU01DD/AU01DM/AU01DY	T01D1/T01D2/T01D3/T01D4	AUS/澳洲	
WEL-TRY-R04XBK/R04LBK/R04LC/R04LM/R04LY	R04XBK/R04LBK/R04LC/R04LM/R04LY	LAV拉丁美洲	Epson WorkForce Pro WF-C5210/WF-C5290/WF-C5290/WF-C5710/WF-C5790

连供图片/ciss

填充图片/refillable

兼容成品compatible



WEL-TRY-T372	T372	AP	Epson PictureMate PM-520	
WEL-TRY-T376	T376	LA	Epson PictureMate PM-525	
WEL-TRY-40HBK/40HC/40HM/40HY	T40H1/T40H2/T40H3/T40H4	CHN	Epson SureColor T3180/T5180	
WEL-TRY-41KBK/41KC/41KM/41KY	T41K5/T41K2/T41K3/T41K4	CHN	Epson SureColor T3480/T5480	
WEL-TRY-40DBK/40DC/40DM/40DY	T40D1/T40D2/T40D3/T40D4	EUR	Epson SureColor T3100/T5100	
WEL-TRY-41FBK/41FC/41FM/41FY	T41F5/T41F2/T41F3/T41F4	EUR	Epson SureColor T3400/T5400	
WEL-TRY-SC13MBL/SC13CL/SC13ML/SC13YL	SC13MBL/SC13CL/SC13ML/SC13YL	JPN	Epson SureColor T3150/T5150	

WEL-TRY for Epson VI Series Inkjet Cartridge为彩爱普生6代产品

Product Codex型号	OEM Product 原装型号Code	Region /地区	Description适用打印机
WEL-TRY-T364BK/T364C/T364M/T364Y	T3641/T3642/T3643/T3644	KOR	Epson Expression Home XP-245/442
WEL-TRY-T288XL1/T288XL2/T288XL3/T288XL4	T288XL1/T288XL2/T288XL3/T288XL4	NA/AUS	Epson Expression Home XP-240/XP-330/XP-340/XP-430/XP-434/XP-440/XP-446
WEL-TRY-T2971/T2962/T2963/T2964	T2971/T2962/T2963/T2964	LA	Epson XP-231/431
WEL-TRY-T2991A/T2992A/T2993A/T2994A	T2991/T2992/T2993/T2994	AUS	Epson Expression Home XP-235/ XP-432
WEL-TRY-T2991/T2992/T2993/T2994	T2991/T2992/T2993/T2994	EUR	Epson Expression Home XP-235/XP-245/XP-247/XP-332/XP-335/XP-342/XP-345/XP-432/XP-435/XP-442/XP-445
WEL-TRY-RDHBK/ RDHBK/ RDHC/ RDHM/ RDHY	RDHBK/ RDHBK/ RDHC/ RDHM/ RDHY	JPN	Epson PX-048A/049A
连供图片/ciss		填充图片/refillable	
		兼容成品compatible	




WEL-TRY- T410XL0/T410XL1/T410XL2/T410XL3/T410XL4	T410XL0/T410XL1/T410XL2/T410XL3/T410XL4	NA	Epson Expression Premium XP-530/XP-630/XP-540/XP-640/XP-900/XP-830/XP-7100
WEL-TRY- T410XL0A/T410XL1A/T410XL2A/T410XL3A/T410XL4A	T3391/T3401/T3402/T3403/T3404	AUS	Epson Expression Premium XP-530/XP-630/XP-540/XP-640/XP-900
WEL-TRY- T3351/T3361/T3362/T3363/T3364	T3351/T3361/T3362/T3363/T3364	EUR	Epson Expression Premium XP-530/XP-630/XP-830/XP-635/XP-540/XP-640/XP-645/XP-7100
WEL-TRY- YTHBK/YTHC/YTHM/YTHY/YTHR/YTHGY	YTHBK/YTHC/YTHM/YTHY/YTHR/YTHGY	JPN	Epson EP-10VA/30VA
连供图片/ciss		填充图片/refillable	兼容成品compatible



WEL-TRY- T8021/T8022/T8023/T8024/T8025/T8026/T8027/T8028/T8029/T8020	T8021/T8022/T8023/T8024/T8025/T8026/T8027/T8028/T8029/T8020	CHN	Epson SureColor P10080/P20080
WEL-TRY- T8061/T8062/T8063/T8064/T8065/T8066/T8067/T8068/T8069	T8061/T8062/T8063/T8064/T8065/T8066/T8067/T8068/T8069	CHN	Epson SureColor P6080
WEL-TRY- T8041/T8042/T8043/T8044/T8045/T8046/T8047/T8048/T8049	T8041/T8042/T8043/T8044/T8045/T8046/T8047/T8048/T8049	NA	Epson SureColor P6000
WEL-TRY- SC9BK70/SC9C70/SC9GR70/SC9GY70/SC9LM70/	SC9BK70/SC9C70/SC9GR70/SC9GY70/SC9LM70/SC9MB70/SC9OR70/SC9	JPN	Epson SureColor P6050
填充图片/refillable		兼容成品compatible	



WEL-TRY-T289/T290	T289/T290	CHN	Epson WorkForce WF-100	
-------------------	-----------	-----	------------------------	---


WEL-TRY for Epson V Series Inkjet Cartridge为彩爱普生5代产品

Product Codex型号	OEM Product 原装型号Code	Region /地区	Description适用打印机
WEL-TRY-SATBK/SATC/SATM/SATY/SATLC/SATLM	SATBK/SATC/SATM/SATY/SATLC/SATLM	JPN	Epson EP-712A/EP-812A Coming soon !
WEL-TRY-ITHBK/ITHC/ITHM/ITHY/ITHLC/ITHLM	ITHBK/ITHC/ITHM/ITHY/ITHLC/ITHLM	JPN	Epson EP-709A/EP-710A/EP-810AW/EP-810AB
WEL-TRY-ICBK73L	ICBK73L	JPN	Epson PX-K150
WEL-TRY-ICBK80L/ICC80L/ICM80L/ICY80L/ICLC80L/ICLM80L	ICBK80L/ICC80L/ICM80L/ICY80L/ICLC80L/ICLM80L	JPN	Epson EP-707A/EP-777A/EP-807AB/EP-807AR/EP-807AW/EP-907F/EP-977A3/EP-978A3/ EP-808AW/EP-808AB/EP-808AR/EP-979A3/EP-982A3
WEL-TRY-ICBK80/ICC80/ICM80/ICY80/ICLC80/ICLM80	ICBK80/ICC80/ICM80/ICY80/ICLC80/ICLM80	JPN	

填充图片/refillable	ciss/refillable	兼容成品compatible
-----------------	-----------------	----------------




The image shows three different ink cartridge configurations. On the left is a 'Compatible inkjet cartridge' which is a single unit with multiple color sections. In the middle is a 'CISS' (Continuous Ink Supply System) consisting of a black reservoir and several individual ink cartridges connected by tubes. On the right is a set of six individual ink cartridges labeled E1TH-BK, E1TH-C, E1TH-M, E1TH-Y, E1TH-LC, and E1TH-LM.



WEL-TRY-ICBK82/ICCL82	ICBK82/ICCL82	JPN	Epson PX-S05W/PX-S05B PX-S06W/PX-S06B	
-----------------------	---------------	-----	--	---

WEL-TRY-ICCL81	ICCL81	JPN	Epson PF-71	
WEL-TRY-ICBK78/ICC78/ICM78/ICY78	ICBK78/ICC78/ICM78/ICY78	JPN	Epson PX-M650/PX-M650A/5色填充xp黑色可以用厚填充133但是要能装xp芯片座	
WEL-TRY-ICBK77/ICC78/ICM78/ICY78	ICBK77/ICC78/ICM78/ICY78	JPN		
WEL-TRY-T220XL1/T220XL2/T220XL3/T220XL4	T220XL1/T220XL2/T220XL3/T220XL4	NA	Epson WorkForce WF-2630/WF-2650/WF-2660/WF-2750/WF-2760 Epson Expression Home XP-420/XP-424/XP-320	
WEL-TRY-T2941/T2942/T2943/T2944	T2941/T2942/T2943/T2944	AU	Epson WorkForce WF-2630/WF-2650/WF-2660 Epson Expression Home XP-420/XP-424/XP-320	
连供图片/ciss		填充图片/refillable		兼容成品compatible



WEL-TRY-T266/WEL-TRY-T267	T266/T267	EUR	Epson WorkForce WF-100W	
---------------------------	-----------	-----	-------------------------	---

WEL-TRY for Epson IV Series Inkjet Cartridge 为 彩爱普生4代产品

Product Codex型号	OEM Product 原 装型号Code	Region/ 地区	Description适用打印机
WEL-TRY-T8651	T8651	EUR	Epson WorkForce Pro WF-M5690/WF-M5190 (EUR) 
WEL-TRY-ICBK95L	ICBK95L	JPN	Epson PX-M350F/PX-S350 (JP)
WEL-TRY- ICBK79/ICC79/ICVM79/ICY79/ICLC79/IC GY79/	ICBK79/ICC79/ICVM79/IC Y79/ICLC79/ICGY79/ ICLGY79/ICMB79/ICVLM	JPN	Epson SC-PX5V2 (JP) 
WEL-TRY- T7601/T7602/T7603/T7604/T7605/ T7606/T7607/T7608/T7609	T7601/T7602/T7603/T760 4/T7605/T7606/ T7607/T7608/T7609	EUR	Epson SureColor SC-P600 (EUR)

连供图片/ciss	填充图片/refillable	兼容成品compatible
-----------	-----------------	----------------




WEL-TRY- ICBK88/ICC88/ICM88/ICY88/ICBL88/ICG L88/ ICMB88/ICR88/ICOR88	ICBK88/ICC88/ICM88/ICY 88/ICBL88/ICGL88/ ICMB88/ICR88/ICOR88	JPN	EpsonSC-PX7VII (JP)
WEL-TRY- T3240/T3241//T3242/T3243/T3244/T3247/ T3248/T3249	T3240/T3241//T3242/T32 43/T3244/T3247/T3248/T 3249	NA/EUR	Epson SureColor P400

连供图片/ciss	填充图片/refillable	兼容成品compatible
-----------	-----------------	----------------



WEL-TRY- ICBK89/ICC89/ICVM89/ICY89/ICGY89/ ICLC89/ICLY89/ICMB89/ICVLM89 SAMPLE!	ICBK89/ICC89/ICVM89/IC Y89/ICGY89/ICLC89/ ICLY89/ICMB89/ICVLM 89	JPN	Epson SC-PX3V (JP)	
连供图片/ciss		填充图片/refillable		兼容成品compatible
WEL-TRY-T9731/T9732/T9733/T9734	T9731/T9732/T9733/T9734 4	CHN	Epson WF-C869Ra	
WEL-TRY-T9741/T9742/T9743/T9744	T9741/T9742/T9743/T9744 4	CHN		
WEL-TRY-T8781/T8782/T8783/T8784	T8781/T8782/T8783/T8784 4	EUR	Epson WorkForce Pro WF-R5190/WF-R5690	
WEL-TRY-T9071/T9072/T9073/T9074	T9071/T9072/T9073/T9074 4	EUR	Epson WorkForce Pro WF-6590D2TWFC/6590DTWC/6590DW/ 6090D2TWFC/6090DTWC/6090DW	
WEL-TRY-T9081/T9082/T9083/T9084	T9081/T9082/T9083/T9084 4	EUR		
连供/ciss		填充墨盒/refillable		兼容墨袋compatible
WEL-TRY-T215BK/WEL-TRY-T215CL	T2151/T2153	NA/AU	Epson WorkForce WF-100W (EUR/US)	
WEL-TRY-T2231/T223XL1	T2231/T223XL1	NA	Epson WorkForce WF-M1030/M1560 (NA) 加厚填充xp	
WEL-TRY-T2511	T2511	HK	Epson WorkForce WF-M1561(HK)填充xp单黑	
WEL-TRY-T1801/T1802/T1803/T1804	T1801/T1802/T1803/T1804 4	EUR	Epson Expression Home XP-30/XP-102/XP-202/XP-205/XP-302/XP-305/ XP-402/XP-405/XP-215/XP-312/XP-415 (EUR)	
WEL-TRY-T1811/T1812/T1813/T1814	T1811/T1812/T1813/T1814 4	EUR		
WEL-TRY-T2001/T2002/T2003/T2004	T2001/T2002/T2003/T2004 4	NA	Epson Expression Home XP-200/XP-300/XP-400/XP-310/XP-410/XP-510 Epson WorkForce WF-2520/WF-2530/WF-2540 (NA)	

WEL-TRY-T200XL1/T200XL2/T200XL3/T200XL4	T200XL1/T200XL2/T200XL3/T200XL4	NA	Epson Expression Home XP-200/XP-300/XP-400/XP-310/XP-410/XP-510 Epson WorkForce WF-2520/WF-2530/WF-2540 (NA)
WEL-TRY-T1701/T1702/T1703/T1704	T1701/T1702/T1703/T1704	Russia	Epson Expression Home XP-103/XP-203/XP-207/XP-313/XP-413 (Russia)
WEL-TRY-T1711/T1712/T1713/T1714	T1711/T1712/T1713/T1714	Russia	
WEL-TRY-T1621/T1622/T1623/T1624	T1621/T1622/T1623/T1624	EUR	Epson WorkForce WF-2010W/WF-2510WF/WF-2520NF/WF-2530DW/ WF-2540WF/WF-2750DWF/2760DWF (EUR)
WEL-TRY-T1631/T1632/T1633/T1634	T1631/T1632/T1633/T1634	EUR	
WEL-TRY-T1901/T1902/T1903/T1904	T1901/T1902/T1903/T1904	AP	Epson ME401/ME303 (CHN)
WEL-TRY-T1911/T1902/T1903/T1904	T1911/T1902/T1903/T1904	AP	
WEL-TRY-T1931/T1932/T1933/T1934	T1931/T1932/T1933/T1934	AP	Epson WorkForce WF-2521/WF-2531/WF-2541 (AP)
WEL-TRY-T1981/T1932/T1933/T1934	T1981/T1932/T1933/T1934	AP	
WEL-TRY-1661/1662/1663/1664	T1661/T1662/T1663/T1664	AP	Epson ME-10/ME-101 (CHN) 
WEL-TRY-1671/1662/1663/1664	T1671/T1662/T1663/T1664	AP	
WEL-TRY-1761/1762/1763/1764	T1761/T1762/T1763/T1764	AP	Epson Expression Home XP-102/XP-202 (HK)
WEL-TRY-1771/1772/1773/1774	T1771/T1772/T1773/T1774	AP	Epson Expression Home XP-102/XP-202/XP-302/XP-402 (HK)
WEL-TRY-1781/1772/1773/1774	T1781/T1772/T1773/T1774	AP	Epson Expression Home XP-302/XP-402 (HK)
WEL-TRY-T1971/T1962/T1963/T1964	T1971/T1962/T1963/T1964	LA	Epson Expression XP-204/XP-211/XP-214/XP-401 (LA)
WEL-TRY-ICBK69/ICC69/ICM69/ICY69	ICBK69/ICC69/ICM69/ICY69	JPN	Epson PX-535F/PX-045A/PX-405A/PX-435A (JP)
WEL-TRY-ICBK69L/ICC69/ICM69/ICY69	ICBK69L/ICC69/ICM69/ICY69	JPN	
WEL-TRY-ICBK74/ICC74/ICM74/ICY74	ICBK74/ICC74/ICM74/ICY74	JPN	Epson PX-S5040/PX-M5040F/PX-M5041F (JP)这款可以用加厚xp
WEL-TRY-ICBK76/ICC76/ICM76/ICY76	ICBK76/ICC76/ICM76/ICY76	JPN	
WEL-TRY-ICBK75/ICC75/ICM75/ICY75	ICBK75/ICC75/ICM75/ICY75	JPN	Epson PX-M741F/PX-M740F/PX-S740 (JP)这款可以用加厚xp
WEL-TRY-T2701/T2702/T2703/T2704	T2701/T2702/T2703/T2704	EUR	Epson WorkForce WF-7110 DTW/WF-7610 DWF/WF-7620 DTWF/WF-3620/ WF-3640DTWF/WF-7715DWF/WF-7710DWF/WF-7210DTW (EUR)
WEL-TRY-T2711/T2712/T2713/T2714	T2711/T2712/T2713/T2714	EUR	
WEL-TRY-T2791/T2712/T2713/T2714	T2791/T2712/T2713/T2714	EUR	
WEL-TRY-T2521/T2522/T2523/T2524	T2521/T2522/T2523/T2524	NA/AU	Epson WorkForce WF-3620/WF-3640/WF-7610/WF-7620/WF-7710/WF-7720/ WF-7210 (NA)黑色可以用加厚填充xp
WEL-TRY-T252XL1/T252XL2/T252XL3/T252XL4	T252XL1/T252XL2/T252XL3/T252XL4	NA/AU	
WEL-TRY-T1881/T1882/T1883/T1884	T1881/T1882/T1883/T1884	AP	Epson WF-7621/WF-7111/WF-3641 (CHN)这款黑色可以用加厚填充xp

连供图片/ciss

填充图片/refillable

兼容成品compatible




WEL-TRY-T7551/T7552/T7553/T7554	T7551/T7552/T7553/T7554	EUR	Epson Pro WF-8090/8590/8010/8510(EUR)
---------------------------------	-------------------------	-----	---------------------------------------

WEL-TRY- ICBK93L/ICC93L/ICM93L/ICY93L	ICBK93L/ICC93L/ICM93L/ ICY93L	JPN	Epson PX-M7050F/PX-M7050FP/PX-M7050FT Epson PX-S7050/PX-S7050PS (JP)	
WEL-TRY- ICBK93M/ICC93M/ICM93M/ICY93M	ICBK93M/ICC93M/ICM93 M/ICY93M	JPN		
连供/ciss		填充墨盒/refillable		兼容墨袋compatible



WEL-TRY- T2601/T2611/T2612/T2613/T2614	T2601/T2611/T2612/T261 3/T2614	EUR	Epson Expression Premium XP-600/XP-605/XP-700/XP-800/XP-610/ XP-615/XP-710/XP-810 (EUR)	
WEL-TRY- T2621/T2631/T2632/T2633/T2634	T2621/T2631/T2632/T263 3/T2634	EUR		
WEL-TRY- T2421/T2422/T2423/T2424/T2425/T2426	T2421/T2422/T2423/T242 4/T2425/T2426	EUR	Epson Expression Photo XP-750/XP-850/XP-950/XP-860/XP-55/XP- 760/XP-960 (EUR)	
WEL-TRY- T2431/T2432/T2433/T2434/T2435/T2436	T2431/T2432/T2433/T243 4/T2435/T2436	EUR		
WEL-TRY- T2771/T2772/T2773/T2774/T2775/T2776	T2771/T2772/T2773/T277 4/T2775/T2776	NA	Epson Expression Premium XP-850/XP-950/XP-860/XP-960 (NA)	
WEL-TRY- T277XL1/T277XL2/T277XL3/T277XL4/T27 7XL5/T277XL6	T277XL1/T277XL2/T277X L3/T277XL4/T277XL5/T27 7XL6	NA		
WEL-TRY- T2730/T2731/T2732/T2733/T2734	T2730/T2731/T2732/T273 3/T2734	NA	Epson Expression Premium XP-600/XP-800/XP-610/XP-810 (NA)	
WEL-TRY- T273XL0/T273XL1/T273XL2/T273XL3/T27 3XL4	T273XL0/T273XL1/T273X L2/T273XL3/T273XL4	NA		
WEL-TRY- T2551/T2561/T2562/T2563/T2564	T2551/T2561/T2562/T256 3/T2564	AP	Epson Expression Premium XP-701 (CHN/HK)	
WEL-TRY- T2690/T2691/T2692/T2693/T2694	T2690/T2691/T2692/T269 3/T2694	LA	Epson Expression Premium XP-702/802 (LA)	
WEL-TRY- ICBK70/ICC70/ICM70/ICY70/ICLC70/ICL M70	ICBK70/ICC70/ICM70/ICY 70/ICLC70/ICLM70	JPN	Epson EP-905F/EP-775AW/EP-805AW/EP-706A/EP-776A (JP)	
WEL-TRY- ICBK70L/ICC70L/ICM70L/ICY70L/ICLC70 L/ICLM70L	ICBK70L/ICC70L/ICM70L/ ICY70L/ICLC70L/ICLM70 L	JPN		
填充图片/refillable		ciss/refillable		兼容成品compatible





WEL-TRY- T6941/T6942/T6943/T6944/T6945	T6941/T6942/T6943/T694 4/T6945	NA/EUR	Epson SureColor T3000/T5000/T7000 Epson SureColor T3200/T5200/T7200 Epson SureColor T3270/T5270/T7270
WEL-TRY- T6931/T6932/T6933/T6934/T6935	T6931/T6932/T6933/T693 4/T6935		

WEL-TRY-T7081/T7072/T7073/T7074/T7075	T7081/T7072/T7073/T7074/T7075	CHN	Epson SureColor T3080/T3280/T5280/T7280
WEL-TRY-SC1BK70/SC1C70/SC1M70/SC1Y70/SC1MB70	SC1BK70/SC1C70/SC1M70/SC1Y70/SC1MB70	JPN	Epson SureColor T3050/T3250/T5050/T5250/T7050/T7250
WEL-TRY-T7411/T7412/T7413/T7414	T7411/T7412/T7413/T7414	NA/EUR	Epson SureColor F6000/F6070/F7000/F7100/F7070/F7170/F7200
WEL-TRY-T741X/T7412/T7413/T7414	T741X/T7412/T7413/T7414	NA/EUR	Epson SureColor F6000/F6200/F7000/F7100/F7200/F9200/F9300/F9370
WEL-TRY-T7421/T7422/T7423/T7424	T7421/T7422/T7423/T7424	CHN	Epson SureColor F6080/F7180/F7080 (CHN)
WEL-TRY-T742X/T7422/T7423/T7424	T742X/T7422/T7423/T7424	CHN	Epson SureColor F9380
WEL-TRY-T7251/T7252/T7253/T7254/T725A	T7251/T7252/T7253/T7254/T725A	NA/EUR	Epson SureColor F2000
WEL-TRY-T7261/T7262/T7263/T7264/T726A	T7261/T7262/T7263/T7264/T726A	CHN	Epson SureColor F2080
WEL-TRY-T6871/T6872/T6873/T6874	T6871/T6872/T6873/T6874	EUR	Epson SureColor S30600/S50600
WEL-TRY-T6881/T6882/T6883/T6884	T6881/T6882/T6883/T6884	EUR	Epson SureColor S30610/S50610
WEL-TRY-T6891/T6892/T6893/T6894	T6891/T6892/T6893/T6894	NA	Epson SureColor S30670/S50670
WEL-TRY-T8931/T8932/T8933/T8934/T8935/T8936/T8937/T8938/T8939	T8931/T8932/T8933/T8934/T8935/T8936/T8937/T8938/T8939	CHN	Epson SureColor S40680/S60680/S80680

兼容墨盒/compatible

填充墨盒+维护箱refillable+maintenance box



WEL-TRY-T6193	T6193	/	Epson T3000 
WEL-TRY-T8391/T8392/T8393/T8394	T8391/T8392/T8393/T8394	EUR	Epson WorkForce Pro WF-R8590 
WEL-TRY-T786XL1/T786XL2/T786XL3/T786XL4	T786XL1/T786XL2/T786XL3/T786XL4	NA	Epson WorkForce Pro WF-5620/WF-5690/WF-5110/WF-5190 (US)
WEL-TRY-ICBK92M/ICC92M/ICM92M/ICY92M	ICBK92M/ICC92M/ICM92M/ICY92M	JPN	Epson PX-M840/PX-S840(JP)
WEL-TRY-ICBK92L/ICC92L/ICM92L/ICY92L	ICBK92L/ICC92L/ICM92L/ICY92L	JPN	
WEL-TRY-T7891/T7892/T7893/T7894	T7891/T7892/T7893/T7894	EUR	Epson WorkForce Pro WF-5620DWF/WF-5690DWF/WF-5110DW/WF-5190DW (EUR)
WEL-TRY-T7901/T7902/T7903/T7904	T7901/T7902/T7903/T7904	EUR	Epson WorkForce Pro WF-5620DWF/WF-5690DWF/WF-5110DW/WF-5190DW
WEL-TRY-T7911/T7912/T7913/T7914	T7911/T7912/T7913/T7914	EUR	Epson WorkForce Pro WF-4640/WF-4630 (EUR)

填充图片/refillable


ciss/refillable

兼容成品compatible



<p>WEL-TRY- T8501/T8502/T8503/T8504/T8505/T8506/T8507/T8508/T8509</p>	<p>T8501/T8502/ T8503/T8504/ T8505/T8506/ T8507/T8508/ T8509</p>	<p>EUR</p>	<p>Epson SureColor P800</p>
<p>填充图片/refillable</p>		<p>ciss/refillable</p>	<p>兼容成品compatible</p>



<p>WEL-TRY-T6997</p>	<p>T6997</p>	<p>/</p>	<p>Epson SureColor P6000/P6080</p> 
----------------------	--------------	----------	--

WEL-TRY for Epson New 7-pin Series Inkjet Cartridge (III)为彩爱 普生3代系列新产品七触点

Product Codex型号	OEM Product 原装型号Code	Region /地区	Description适用打印机
WEL-TRY-T1241/T1242/T1243/T1244	T1241/T1242/T1243/T1244	NA/北美	Epson Stylus NX125/NX420/NX430/NX330/NX230 Epson Workforce 320/323/325/435 (NA)
WEL-TRY-T1251/T1252/T1253/T1254	T1251/T1252/T1253/T1254	NA/北美	Epson Stylus NX125/NX625/NX420/NX230 Epson Workforce 320/323/325 (NA)
WEL-TRY-T1261/T1262/T1263/T1264	T1261/T1262/T1263/T1264	NA/北美	Epson WorkForce 630/635/60/840/435/545/645/845 Epson Stylus NX430/NX330 Epson WorkForce WF-3520/3540 (NA)
WEL-TRY-T1271/T1272/T1273/T1274	T1271/T1272/T1273/T1274	NA/北美	Epson Stylus NX625 Epson Workforce 630/635/60/840/545/645/845 Epson WorkForce WF-3520/3540 (NA)
WEL-TRY-T1251/T1251/T1252/T1253/T1254	T1251/T1251/T1252/T1253/T1254	NA/北美	Epson Workforce 520 (NA)
WEL-TRY-T1261/T1261/T1262/T1263/T1264	T1261/T1261/T1262/T1263/T1264	NA/北美	Epson Workforce 520 (NA)
WEL-TRY-T1281/T1282/T1283/T1284	T1281/T1282/T1283/T1284	EUR/欧洲	Epson Stylus S22/SX125/SX420W/SX425W/SX235W/SX130/ SX435W/SX230/SX440W Epson Stylus Office BX305F/BX305FW (EUR)
WEL-TRY-T1291/T1292/T1293/T1294	T1291/T1292/T1293/T1294	EUR/欧洲	Epson Stylus SX420W/SX425W/SX525WD/SX620FW/ SX445/SX235W/SX435W/SX230/SX440W/SX535WD Epson Stylus Office BX305F/BX305FW/BX525WD/BX625FWD/ B42WD/BX925FWD/BX925FW/BX535WD/BX635FWD/BX935FWD Epson WorkForce WF-3540DTWF (EUR)
WEL-TRY-T1301/T1302/T1303/T1304	T1301/T1302/T1303/T1304	EUR/欧洲	Epson Stylus SX525WD/SX620FW/SX445/SX535W Epson Stylus Office BX525WD/BX625FWD/BX925FWD/B42WD/ BX925FW/BX535WD/BX635FWD/BX935FWD Epson WorkForce WF-3540DTWF (EUR)
WEL-TRY-T1291/T1291/T1292/T1293/T1294	T1291/T1291/T1292/T1293/T1294	EUR/欧洲	Epson Stylus Office BX320FW (EUR)
WEL-TRY-T1321/T1322/T1323/T1324	T1321/T1322/T1323/T1324	NA/北美	Epson Stylus N11 Epson NX125 (AU)
WEL-TRY-T1331/T1332/T1333/T1334	T1331/T1332/T1333/T1334	NA/ASIA北美 /亚洲	Epson Stylus N11/NX420/T12/T22/TX120/NX125/TX129/ TX420W/TX235/TX430W/NX230/TX130 Epson Workforce 320/435 (AU/AP)
WEL-TRY-T1381/T1382/T1383/T1384	T1381/T1382/T1383/T1384	NA/ASIA北美 /亚洲	Epson Stylus NX420/TX420W/TX235/TX430W/NX230 Epson Workforce 320/630/633/435 (AU/AP)
WEL-TRY-T1401/T1402/T1403/T1404	T1401/T1402/T1403/T1404	NA/北美	Epson Workforce 630/633 Epson Stylus Office TX620FWD Epson Stylus TX560WD (AU)
WEL-TRY-T1411/T1412/T1413/T1414	T1411/T1412/T1413/T1414	AP/亚太地区	Epson ME 32/33/320/330/35/350/340 Epson ME Office 620F/560W/570W/960FWD/900WD/535/85ND Epson WF-7018 (AP)
WEL-TRY-T1431/T1432/T1433/T1434	T1431/T1432/T1433/T1434	AP/亚太地区	Epson ME Office 960FWD/900WD/940FW/85ND Epson WF-7018 (AP)
WEL-TRY-T1731/T1732/T1733/T1734	T1731/T1732/T1733/T1734	AP/亚太地区	Epson ME 35/350 (Asia-Pacific)
WEL-TRY-T1421/T1412/T1413/T1414	T1421/T1412/T1413/T1414	AP/亚太地区	Epson ME Office 620F/560W (AP)
WEL-TRY-T1371/T1371	T1371/T1371	AP/亚太地区	Epson K100/K200 (AP)
WEL-TRY-T1321/T1332/T1333/T1334	T1321/T1332/T1333/T1334	SA/LA拉丁 美洲/南美	Epson Stylus T22/TX120 (SA)
WEL-TRY-T1351/T1332/T1333/T1334	T1351/T1332/T1333/T1334	SA/LA拉丁 美洲/南美	Epson Stylus T25/TX125/TX135 (SA)
WEL-TRY-T1381/T1332/T1333/T1334	T1381/T1332/T1333/T1334	SA/LA拉丁 美洲/南美	Epson Stylus TX420W/TX320F/TX235W (SA)
WEL-TRY-T1381/T1381/T1402/T1403/T1404	T1381/T1381/T1402/T1403/T1404	SA/LA拉丁 美洲/南美	Epson Stylus Office TX525FW (SA)

WEL-TRY-T1361/T1361	T1361/T1361	LA/拉丁美洲	Epson WorkForce K101 (SA)厚填充133两个黑色
WEL-TRY-ICBK67/ICBK67	ICBK67/ICBK67	JPN/日本	Epson PX-K100 (JP)厚填充133两个黑色
WEL-TRY-ICBK62/ICC62/ICM62/ICY62	ICBK62/ICC62/ICM62/ICY62	JPN/日本	Epson PX-430A/PX-403A/PX-404A/PX-434A/PX-675F (JP)黑色可以用厚填充133
WEL-TRY-ICBK61/ICC62/ICM62/ICY62	ICBK61/ICC62/ICM62/ICY62	JPN/日本	Epson PX-503A/603F/203/PX-675F (JP)/黑色可以用厚填充133
WEL-TRY-ICBK61/ICC65/ICM65/ICY65	ICBK61/ICC65/ICM65/ICY65	JPN/日本	Epson PX-673F/1600F/1200/1700F (JP)/黑色可以用厚填充133
填充图片/refillable		ciss/refillable	兼容成品compatible



WEL-TRY-T1590/T1591/T1592/T1593/T1594/T1597/T1598/T1599	T1590/T1591/T1592/T1593/T1594/T1597/T1598/T1599	NA/北美	Epson Stylus Photo R2000(8 colors)
填充图片/refillable		ciss/refillable	兼容成品compatible



WEL-TRY- T1571/T1572/T1573/T1574/T1575/T1576/ T1577/T1578/T1579	T1571/T1572/T1573/T1574/T1575/T1576/T1577/T1578/T1579	NA/北美	Epson Stylus Photo R3000(9 colors)
WEL-TRY- ICBK64/ICMB64/ICC64/ICVM64/ICY64/IC LC64/ ICVLM64/ICGY64/ICLG64	ICBK64/ICMB64/ICC64/IC VM64/ICY64/ ICLC64/ICVLM64/ICGY64 /ICLG64	JPN/日本	Epson Stylus Photo PX-5V(9 colors) (JP)
填充图片/refillable		ciss/refillable	
		兼容成品compatible	



No. E095

Model: 长P600 (带盖)
Volume: 80ml
For use: Refillable ink cartridge.

28+ Years Industry Manufacturer & Price & Quality Guaranteed.

WEL-TRY-T7441	T7441	AP/亚太地区	Epson WorkForce Pro WP-M4015dn 
WEL-TRY-T6761/T6762/T6763/T6764	T676XL1/T676XL2/T676XL3/T676XL4	gobal/全球	WorkForce Pro (WP-Series) WP-4520/4530/4533/4540/4590/4010/4020/4023/4090 (NA)
WEL-TRY-T6771/T6772/T6773/T6774	T6771/T6772/T6773/T6774	CHN/中国	Epson WorkForce Pro WP-4511/WP-4531/WP-4521 (CHN)

WEL-TRY-T6781/T6782/T6783/T6784	T6781/T6782/T6783/T6784 4	CHN/中国	Epson WorkForce Pro WP-4011/WP-4511/WP-4521 (CHN)
WEL-TRY-T7011/T7012/T7013/T7014	T7011/T7012/T7013/T7014 4	EUR/欧洲	Epson WorkForce Pro WP-4025/WP-4015/WP-4525/WP-4545/WP-4595 (EUR)
WEL-TRY-T7021/T7022/T7023/T7024	T7021/T7022/T7023/T7024 4	EUR/欧洲	
WEL-TRY-T7031/T7032/T7033/T7034	T7031/T7032/T7033/T7034 4	EUR/欧洲	
WEL-TRY-T7111/T7112/T7113/T7114	T711XXL120/T711XXL220/T711XXL320/T711XXL420	EUR/欧洲	Epson WorkForce Pro WP-4590/4023
WEL-TRY-ICBK90M/ICC90M/ICM90M/ICY90M	ICBK90M/ICC90M/ICM90M/ICY90M	JPN/日本	Epson PX-B750F/B700 (JP)
WEL-TRY-ICBK90L/ICC90L/ICM90L/ICY90L	ICBK90L/ICC90L/ICM90L/ICY90L	JPN/日本	



填充图片/refillable	ciss/refillable	兼容成品compatible
-----------------	-----------------	----------------



Refillable cartridge without ink bag

Compatible cartridge with ink bag inside

CISS



WEL-TRY-T6551/T6552/T6553/T6554/T6555/T6556/T6557/T6558/T6559/T655A/T655B	T6551/T6552/T6553/T6554/T6555/T6556/T6557/T6558/T6559/T655A/T655B	gobal/全球	Epson Stylus Pro 4910
WEL-TRY-T6531/T6532/T6533/T6534/T6535/T6536/T6537/T6538/T6539/T653A/T653B	T6531/T6532/T6533/T6534/T6535/T6536/T6537/T6538/T6539/T653A/T653B	gobal/全球	Epson Stylus Pro 4900
WEL-TRY-T9131/T9132/T9133/T9134/T9135/T9136/T9137/T9138/T9139/T913A/T913B/T913D	T9131/T9132/T9133/T9134/T9135/T9136/T9137/T9138/T9139/T913A/T913B/T913D	NA/EUR北美/欧洲	Epson SureColor P5000
WEL-TRY-T9151/T9152/T9153/T9154/T9155/T9156/T9157/T9158/T9159/T915A/T915B/T915D	T9151/T9152/T9153/T9154/T9155/T9156/T9157/T9158/T9159/T915A/T915B/T915D	CHN/中国	Epson SureColor P5080

兼容墨袋compatible	填充墨盒/refillable	refillable
----------------	-----------------	------------



WEL-TRY-T6190	T6190(废墨仓)	gobal/全球	Epson Stylus Pro 4900/4910
WEL-TRY-T5820	T5820(废墨仓)	gobal/全球	Epson SureLab D700 Epson SureColor P800 Epson SC-PX3V Epson SureLab D800
WEL-TRY-T6710/T6711	T6710/T6711	WW/全球	Epson WorkForce Pro WP-4015/WP-4025/WP-4095/WP-4515/WP-4525/WP-4535/WP-4545/WP-4595/WP-M4015/WP-M4095/WP-M4525/WP-M4595/WF-4630/WF-4640/WF-5110/WF-5190/WF-5620/WF-5690/WF-M5190/WF-M5690/WF-R5190/WF-R5690
WEL-TRY-T6712	T6712	WW/全球	Epson WorkForce Pro WF-6090/WF-6590/WF-8090/WF-8010/WF-8510/WF-8590/WF-R8590

WEL-TRY for Epson 9-pin Series Inkjet Cartridge (II)为彩爱普生2代产品九触点

Product Code为彩型号	OEM Product Code原装型号	Region/地区	Description/打印机
WEL-TRY-T6361/T6362//T6363/T6364/T6365/T6366/T6367/T6368/T6369/T636A/T636B	T6361/T6362//T6363/T6364/T6365/T6366/T6367/T6368/T6369/T636A/T636B	gobal/全球	Epson Stylus Pro 7700/7900(EUR)
WEL-TRY-5971/5972/5973/5974/5975/5976/597A/597B/5978	T5971/T5972/T5973/T5974/T5975/T5976/T597A/T597B/T5978	gobal/全球	Epson Stylus Pro 7910/9910/7710/9710



WEL-TRY-0731N/0732N/0733N/0734N	T0731N/T0732N/T0733N/T0734N	gobal/全球	Epson Stylus T10/T11/T20/T21/T40W/T13/TX220/T20E/TX213/Epson Stylus/TX100/TX101/TX200/TX209/TX110/TX210/TX300F/TX121/Epson Stylus/TX400/TX409/TX550W/TX610/TX600FW/TX410/Epson Stylus C79/CX8300/CX5500
WEL-TRY-0731HN/0732N/0733N/0734N	T0731HN/T0732N/T0733N/T0734N	gobal/全球	Epson Stylus T40W/TX550W/TX410/TX200/TX400/Epson Stylus/TX610/TX600FW/C110/C7300/CX8300/C9300F/TX200/TX210/TX220/TX300F/TX510FN/TX400/TX550W/T30/T1100
WEL-TRY-0851N/0852N/0853N/0854N/0855N/0856N	T0851N/T0852N/T0853N/T0854N/T0855N/T0856N	gobal/全球	Epson Stylus T60
WEL-TRY-0901N/0732N/0733N/0734N	T0901N/T0732N/T0733N/T0734N	gobal/全球	Epson Stylus T20/TX100
WEL-TRY-0911N/0912N/0913N/0914N	T0911N/T0912N/T0913N/T0914N	gobal/全球	Epson Stylus TX101/T21/TX110/TX210/TX111/TX610/TX121/C91
WEL-TRY-0921N/0922N/0923N/0924N	T0921N/T0922N/T0923N/T0924N	gobal/全球	Epson Stylus T26/T27/TX117/TX119/TX106/TX109/CX4300/C91
WEL-TRY-0981/0982/0983/0984/0985/0986	T0981/T0982/T0983/T0984/T0985/T0986	gobal/全球	Epson Artisan 600/700/800/710/810/725/835/837/730
WEL-TRY-0981/0992/0993/0994/0995/0996	T0981/T0992/T0993/T0994/T0995/T0996	gobal/全球	
WEL-TRY-0811N/0812N/0813N/0814N/0815N/0816N	T0811N/T0812N/T0813N/T0814N/T0815N/T0816N	gobal/全球	Epson Stylus Photo TX700/TX800/T50/TX710W/TX650/TX810FW/TX820FWD Epson Stylus RX615/R270/R290/Epson Artisan 1430/837
WEL-TRY-0821N/0822N/0823N/0824N/0825N/0826N	T0821N/T0822N/T0823N/T0824N/T0825N/T0826N	gobal/全球	Epson Stylus Photo TX700/TX800/TX710W/TX650/TX810FW/TX820FWD Epson Stylus Photo RX615/R270/R290/Epson Stylus Photo T50/T59/Epson Artisan 837
WEL-TRY-1171/0732N/0733N/0734N	T1171/T0732N/T0733N/T0734N	gobal/全球	Epson Stylus T23/T24/TX105/TX115
WEL-TRY-1031/1032/1033/1034	T1031/T1032/T1033/T1034	gobal/全球	Epson Stylus T40W/TX600FW/TX550W/TX610
WEL-TRY-0961/0962/0963/0964/0965/0966/0967/0968/0969	T0961/T0962/T0963/T0964/T0965/T0966/T0967/T0968/T0969	gobal/全球	Epson Stylus Photo R2880
WEL-TRY-0731HN/0731HN/0732N/0733N/0734N	T0731HN/T0731HN/T0732N/T0733N/T0734N	gobal/全球	Epson Stylus T30
WEL-TRY-1151/1151/0732N/0733N/0734N	T1151/T1151/T0732N/T0733N/T0734N	gobal/全球	Epson Stylus T33
WEL-TRY-1151/1151/1032/1033/1034	T1151/T1151/T1032/T1033/T1034	gobal/全球	Epson Stylus TX515FN
WEL-TRY-0971/0682/0683/0684	T0971/T0682/T0683/T0684	gobal/全球	Epson WorkForce 40/500/600/610/615 Epson WorkForce NX510/515
WEL-TRY-1001/1002/1003/1004	T1001/T1002/T1003/T1004	gobal/全球	Epson Stylus SX600FW/SX510W
WEL-TRY-1231/1232/1233/1234	T1231/T1232/T1233/T1234	gobal/全球	Epson Stylus ME OFFICE 80W/700FW
WEL-TRY-1191/1191/1092/1093/1094	T1191/T1191/T1092/T1093/T1094	gobal/全球	Epson ME OFFICE 70/1100
WEL-TRY-1191/1191/1232/1233/1234	T1191/T1191/T1232/T1233/T1234	gobal/全球	Epson ME OFFICE 1100
WEL-TRY-1091/1091/1092/1093/1094	T1091/T1091/T1092/T1093/T1094	gobal/全球	

WEL-TRY-1091/1092/1093/1094	T1091/T1092/T1093/T1094	gobal/全球	Epson ME 30/ME360/ME300/ Epson ME OFFICE 70
WEL-TRY-0691/0692/0693/0694	T0691/T0692/T0693/T0694	gobal/全球	Epson Stylus CX7400/CX7000F/CX6000/CX5000/Epson/Stylus/CX8400/CX9400FAX/CX7450/CX9475FAX/Epson n/Stylus/NX100/NX115/NX200/NX215/NX400/NX300/NX415/NX105/NX110/NX305/NX51/NX515 /Epson Workforce 30/500/600/610/615/40
WEL-TRY-0691/0691/0692/0693/0694	T0691/T0691/T0692/T0693/T0694	gobal/全球	Epson Stylus WorkForce 30/310/315/1100 
WEL-TRY-0681/0681/0692/0693/0694	T0681/T0681/T0692/T0693/T0694	gobal/全球	Epson Stylus C120
WEL-TRY-0681/0682/0683/0684	T0681/T0682/T0683/T0684	gobal/全球	Epson WorkForce 40/500/600/610/615 Epson NX510/515/CX5000/CX6000/CX7000F/CX8400/CX9400/CX9475
WEL-TRY-0711/0712/0713/0714	T0711/T0712/T0713/T0714	gobal/全球	Epson Stylus D78/D92/DX7000F/DX5000/ DX4050/4000/4400/4450/DX5050/DX6000 Epson Stylus DX6050/DX7400/DX7450/DX8400/DX8450/DX9400/DX9400F/Epson Stylus S20/S21/Epson Stylus SX100/SX110/SX200/SX209/SX210/SX400/SX510W Epson Stylus SX410/SX610FW/SX600FW/SX205/SX215/SX105/SX405 Epson Stylus BX310FN/BX300F/BX3450F/BX600FW/BX610FW/B40W
WEL-TRY-0711H/0712/0713/0714	T0711H/T0712/T0713/T0714	gobal/全球	Epson Stylus SX410/SX510W
WEL-TRY-0731/0732/0733/0734	T0731/T0732/T0733/T0734	gobal/全球	Epson Stylus C79/C90/C92/Epson Stylus CX3900/CX4900/CX4905/CX5900F/CX6900F/Epson Stylus CX7310/8300/CX7300/Epson Stylus CX5500/CX5501/CX5505/CX5510
WEL-TRY-0731H	T0731H	gobal/全球	Epson CX3900/ CX3905/CX4900/CX4905/CX5500/CX5501/CX5505/CX5510/CX5600 T0731N/CX5900/CX6900F/CX7300/CX7310/CX8300/ CX9300/ CX9300F/C79/C90/C92/C110/T10/T11/T13/T13X/T20/T20E/ T22E/T21/T30/T33/T40W/TX100/TX101/TX102/TX103/TX11
WEL-TRY-0881/0882/0883/0884	T0881/T0882/T0883/T0884	gobal/全球	Epson Stylus CX4400/CX4450/CX7400/CX7450/N11 Epson Stylus NX200/NX400/NX100/NX115/NX105/NX110/ NX215/NX300/NX305/NX415/NX510
WEL-TRY-0891/0892/0893/0894	T0891/T0892/T0893/T0894	gobal/全球	Epson Stylus S20/S21 Epson Stylus SX100/SX105/SX115/SX110/SX210/SX215/SX218/SX415 Epson Stylus SX200/SX205/SX400/SX405/SX410/SX510W
WEL-TRY-0911/0912/0913/0914	T0911/T0912/T0913/T0914	gobal/全球	Epson Stylus C90/CX5500/CX5501/CX5510/CX5505
WEL-TRY-0901/0732/0733/0734	T0901/T0732/T0733/T0734	gobal/全球	Epson Stylus C92/C90/CX5600/T20/T21/TX110
WEL-TRY-0921/0922/0923/0924	T0921/T0922/T0923/T0924	gobal/全球	Epson Stylus C91/CX4300
WEL-TRY-0771/0772/0773/0774/0775/0776	T0771/T0772/T0773/T0774/T0775/T 0776	gobal/全球	Epson Stylus Photo R260/R380/R280 Epson Stylus Photo RX580/RX680/RX595 Epson Artisan 50
WEL-TRY-0781/0782/0783/0784/0785/0786	T0781/T0782/T0783/T0784/T0785/T 0786	gobal/全球	Epson Stylus Photo R260/R380/R280 Epson Stylus Photo RX580/RX680/RX595 Epson Artisan 50
WEL-TRY-0791/0792/0793/0794/0795/0796	T0791/T0792/T0793/T0794/T0795/T 0796	gobal/全球	Epson Stylus Photo 1400/PX700W/PX800FW/P50/PX830FWD Epson Artisan 1430
WEL-TRY-0801/0802/0803/0804/0805/0806	T0801/T0802/T0803/T0804/T0805/T 0806	gobal/全球	Epson Stylus Photo R265/R360/R285 Epson Stylus Photo RX585/RX685/RX560 Epson Stylus Photo P50/PX820FWD/PX830FWD Epson Stylus PX700W/PX710W/PX800FW/PX810/PX650/ PX50/PX660/PX720WD/PX730WD
WEL-TRY-0811/0812/0813/0814/0815/0816	T0811/T0812/T0813/T0814/T0815/T 0816	gobal/全球	Epson Stylus Photo R390/RX590/R270/RX690/RX610/RX615/R290/R295 Epson Stylus photo 1410
WEL-TRY-0821/0822/0823/0824/0825/0826	T0821/T0822/T0823/T0824/T0825/T 0826	gobal/全球	Epson Stylus R390/R270/R290/R295 Epson Stylus RX590/RX615/RX610/RX690
WEL-TRY-0851/0852/0853/0854/0855/0856	T0851/T0852/T0853/T0854/T0855/T 0856	gobal/全球	Epson Stylus Photo 1390
WEL-TRY-0870/0871/0872/0873/0874/0877/0878/0879	T0870/T0871/T0872/T0873/T0874/T 0877/T0878/T0879	gobal/全球	Epson Stylus Photo R1900



Compatible inkjet cartridge



Refillable inkjet cartridge



continuous ink supply system



Refillable inkjet cartridge



Compatible inkjet cartridge



T0961,T0962,T0963,T0964,
T0965,T0966,T0967,T0969.
use for : R2880
(LLK/LM/LC/LK/PK/C/M/Y)



Refillable inkjet cartridge



Compatible inkjet cartridge



T0870,T0871,T0872,T0873,
T0874,T0877,T0878,T0879.
for use on Epson: R1900.
(Y/M/MBK/RED/OR/PBK/GLOSS/C)

WEL-TRY for Epson Large Format Application 为彩爱 普生宽幅产品

Product Code	OEM Product Code	Region	Description
WEL-TRY-6071/6072/6073/6074/6075/6076/6077/6079	T6071/T6072/T6073/T6074/T6075/T6076/T6077/T6079	gobal/全球	Epson Stylus Pro 4880 ColorBurst Epson Stylus Pro 4880 Portrait Edition
WEL-TRY-6051/6052/6053/6054/6055/6056/6057/6059	T6051/T6052/T6053/T6054/T6055/T6056/T6057/T6059	gobal/全球	Epson Stylus Pro 4880 ColorBurst Epson Stylus Pro 4880 Portrait Edition(USA)
WEL-TRY-5431/5432/5433/5434/5435/5436/5437	T5431/T5432/T5433/T5434/T5435/T5436/T5437	gobal/全球	Epson Stylus Pro 4000/7600/9600(ULTRACHROME)
WEL-TRY-5438	T5438	gobal/全球	Epson Stylus Pro 4000/4400/4800/7600/9600(ULTRACHROME)
WEL-TRY-5441/5442/5443/5444/5445/5446/5447	T5441/T5442/T5443/T5444/T5445/T5446/T5447	gobal/全球	Epson Stylus Pro4000/9600(ULTRACHROME)
WEL-TRY-5448	T5448	gobal/全球	Epson Stylus Pro 4000/4400/4800/9600(ULTRACHROME)
WEL-TRY-5451/5452/5453/5454/5455/5456	T5451/T5452/T5453/T5454/T5455/T5456	gobal/全球	Epson Stylus Pro7600/9600(ULTRACHROME)
WEL-TRY-5641/5642/5643/5644/5645/5646/5647/5649	T5641/T5642/T5643/T5644/T5645/T5646/T5647/T5649	gobal/全球	Epson Stylus Pro 4800
WEL-TRY-5651/5652/5653/5654/5655/5656/5657/5659	T5651/T5652/T5653/T5654/T5655/T5656/T5657/T5659	gobal/全球	Epson Stylus Pro 4800



Compatible inkjet cartridge(220ml / Color)



Refillable inkjet cartridge (300ml / Color)

WEL-TRY-6041/6042/6043/6044/6045/6046/6047/6049/6128	T6041/T6042/T6043/T6044/T6045/T6046/T6047/T6049/T6128	gobal/全球	Epson Stylus PRO 9880C/7880C
WEL-TRY-5621/5622/5623/5624/5625/5626/5627/5629	T5621/T5622/T5623/T5624/T5625/T5626/T5627/T5629	gobal/全球	Epson Stylus Pro 7800/9800
WEL-TRY-5631/5632/5633/5634/5635/5636/5637/5639	T5631/T5632/T5633/T5634/T5635/T5636/T5637/T5639	gobal/全球	Epson Stylus Pro 7800/9800
WEL-TRY-5662/5663/5664/5668/5678	T5662/T5663/T5664/T5668/T5678	gobal/全球	Epson Stylus Pro 7400/7800/9400/9800
WEL-TRY-5672/5673/5674	T5672/T5673/T5674	gobal/全球	Epson Stylus Pro 7400/9400

220ml/Color



Compatible inkjet cartridge

350ml / Color



without ink bag inside



Refillable inkjet cartridge

with ink bag inside

WEL-TRY-5801/5802/5803/5804/5805/5806/5807/5808/5809	T5801/T5802/T5803/T5804/T5805/T5806/T5807/T5808/T5809	gobal/全球	Epson Stylus Pro 3800/3805
WEL-TRY-5811/5812/5813/5814/5815/5816/5817/5818/5819	T5811/T5812/T5813/T5814/T5815/T5816/T5817/T5818/T5819	gobal/全球	Epson Stylus Pro 3800C
WEL-TRY-5891/5892/5893/5894/5895/5896/5897/5898/5899	T5891/T5892/T5893/T5894/T5895/T5896/T5897/T5898/T5899	gobal/全球	Epson Stylus Pro 3850



Refillable inkjet cartridge



280ml



Continuous ink supply system

WEL-TRY for Epson 7-pin Series Inkjet Cartridge (A/B)为彩爱普生7触点系列产品1代

Product Code为彩型号	OEM Product Code原装型号	Region/地区	Description/打印机
WEL-TRY-007	T007/T008/T009/T017/T018	gobal/全球	Epson Stylus Photo 780/785/785EPX/790/870/875/890/895/900/915/Epson Stylus Photo 1270/1280/1290/1290S/Epson Stylus Photo 825/777/Epson Stylus COLOR 680/685/Epson 1000 ICS



WEL-TRY-015/016	T015/T016	gobal/全球	Epson Stylus Photo 2000SP
-----------------	-----------	----------	---------------------------



WEL-TRY-026/027	T026/T027/T028/T029	gobal/全球	Epson Stylus Photo 810/820/830/830U Epson Stylus Photo 925/935 Epson Stylus Photo C60/C61/CX3100
-----------------	---------------------	----------	--



WEL-TRY-0321/0322/0323/0324	T0321/T0322/T0323/T0324	gobal/全球	Epson Stylus C80/C80WN/C80N
WEL-TRY-0331/0331/0332/0333/0334/0335/0336	T0331/T0331/T0332/T0333/T0334/T0335/T0336	gobal/全球	Epson Stylus Photo 950/960

WEL-TRY-0341/0342/0343/0344/0345/0346/0347/0348	T0341/T0342/T0343/T0344/T0345/T0346/T0347/T0348	gobal/全球	Epson Stylus Photo 2100/2200
WEL-TRY-0321/0422/0423/0424	T0321/T0422/T0423/T0424	gobal/全球	Epson Stylus CX5200/CX5400 Epson Stylus C82/C82N/C82WN
WEL-TRY-0431/0442/0443/0444	T0431/T0442/T0443/T0444	gobal/全球	Epson Stylus C84/C84N/C84WN Epson Stylus CX6400/CX6600



WEL-TRY-036/037	T036/T037	gobal/全球	Epson Stylus C42/C44/C46
WEL-TRY-038/039	T038/T039	gobal/全球	Epson Stylus C41/C43/C43U/C45 Epson Stylus CX1500/CX1500v

WEL-TRY-040/041	T040/T041	gobal/全球	Epson Stylus CX3200/C62
-----------------	-----------	----------	-------------------------



Refillable inkjet cartridge

Compatible inkjet cartridge

CISS



Refillable inkjet cartridge

Compatible inkjet cartridge

CISS



Refillable inkjet cartridge

Compatible inkjet cartridge

WEL-TRY-0441/0442/0443/0444	T0441/T0442/T0443/T0444 4	gobal/全球	Epson Stylus C64/C66/C84/C84N/C84WN/C86 Epson Stylus CX3600/CX3650 Epson Stylus CX4600/CX6400/CX6600
WEL-TRY-0441/0452/0453/0454	T0441/T0452/T0453/T0454 4	gobal/全球	Epson Stylus C64/C66/C84/C86 Epson Stylus CX6600/CX3600/CX3650
WEL-TRY-0461/0472/0473/0474	T0461/T0472/T0473/T0474 4	gobal/全球	Epson Stylus C63/C65/C83/C85 Epson Stylus CX3500/CX4500/CX6300/CX6500
WEL-TRY-0481/0482/0483/0484/0485/0486	T0481/T0482/T0483/T0484 4/T0485/T0486	gobal/全球	Epson Stylus Photo R200/R220/R300/R300M/R320/R340 Epson Stylus Photo RX500/RX600/RX620
WEL-TRY-0491/0492/0493/0494/0495/0496	T0491/T0492/T0493/T0494 4/T0495/T0496	gobal/全球	Epson Stylus Photo R210/R230/R310/R350 Epson Stylus Photo RX510/RX630
WEL-TRY-0540/0541/0542/0543/0544/0547/0548/0549	T0540/T0541/T0542/T0543 3/T0544/T0547/T0548/T0549	gobal/全球	Epson Stylus Photo R800/R1800
WEL-TRY-0551/0552/0553/0554	T0551/T0552/T0553/T0554 4	gobal/全球	Epson Stylus Photo R240/RX420/RX425/RX520
WEL-TRY-05591/05592/05593/05594/05595/05596	T5591/T54592/T5593/T5594 94/T5595/T5596	gobal/全球	Epson Stylus Photo RX700

WEL-TRY-0561/0562/0563/0564	T0561/T0562/T0563/T0564	gobal/全球	Epson Stylus Photo R250/RX430/RX530
WEL-TRY-0591/0592/0593/0594/0595/0596/0597/0598/0599	T0591/T0592/T0593/T0594/T0595/T0596/T0597/T0598/T0599	gobal/全球	Epson Stylus Photo R2400
WEL-TRY-0601/0602/0603/0604	T0601/T0602/T0603/T0604	gobal/全球	Epson Stylus C88 Epson Stylus CX3800/CX3810/CX4200/CX4800/CX5800F/CX7800
WEL-TRY-0611H/0611/0612/0613/0614	T0611H/T0611/T0612/T0613/T0614	gobal/全球	Epson Stylus D88/D68 series/Epson Stylus DX3800/DX3850/Epson Stylus DX4800/DX4850
WEL-TRY-0631/0632/0633/0634	T0631/T0632/T0633/T0634	gobal/全球	Epson Stylus C67/C87/Epson Stylus CX3700/CX4100/CX4700
WEL-TRY-066/067	T066/T067	gobal/全球	Epson Stylus C48
WEL-TRY-0841/0842/8043/0844	T0841/T0842/T0843/T0844	gobal/全球	Epson Stylus Photo 20



Refillable inkjet cartridge Compatible inkjet cartridge continuous ink supply system



Refillable inkjet cartridge Compatible inkjet cartridge continuous ink supply system



Refillable inkjet cartridge Compatible inkjet cartridge continuous ink supply system

WEL-TRY-057/058	T057/T058	gobal/全球	Epson ME 1/ME 100/ME1+
-----------------	-----------	----------	------------------------



Refillable inkjet cartridge



Compatible inkjet cartridge



CISS

WEL-TRY-0557	T0557	gobal/全球	Epson PictureMate 500
WEL-TRY-0573	T0573	gobal/全球	Epson PictureMate 100 Epson PictureMate 100 Mobile Phone Edition



Refillable inkjet cartridge



Compatible inkjet cartridge



continuous ink supply system



Refillable inkjet cartridge



Compatible inkjet cartridge



continuous ink supply system

WEL-TRY-0751/0752/0753/0754	T0751/T0752/T0753 /T0754	gobal/全球	Epson Stylus C59/CX2900/CX2905
WEL-TRY-0761/0762/0763/0764	T0761/T0762/T0763 /T0764	gobal/全球	Epson ME200/ME2/C58



Refillable inkjet cartridge

Compatible inkjet cartridge

continuous ink supply system

WEL-TRY-5846	T5846	gobal/全球	Epson PictureMate Flash-PM280 Epson PictureMate pal-PM 200 Epson PictureMate Snap-PM 240/290/225
WEL-TRY-5852	T5852	gobal/全球	Epson Picture Mate PM210/250/270/235/215/245



Refillable inkjet cartridge

Compatible inkjet cartridge

continuous ink supply system

wel-try gaga series printer为彩嘎嘎2代机系列	T08C1/T08C2/T08C3/T08C4	China/中国	Epson AM-C6000A 生产级墨仓式阵列复合机
wel-try gaga series printer为彩嘎嘎2代机系列	T08C1/T08C2/T08C3/T08C4	China/中国	Epson AM-C5000A 生产级墨仓式阵列复合机
wel-try gaga series printer为彩嘎嘎2代机系列	T08C1/T08C2/T08C3/T08C4	China/中国	Epson AM-C4000A 生产级墨仓式阵列复合机



T08C4
黄色



T08C3
洋红色



T08C2
青色



T08C1
黑色

wel-try gaga series printer为彩嘎嘎机系列	T02Y1 T02Y2/3/4	China/中国	Epson WF-C2100c 生产级墨仓式阵列复合机
wel-try gaga series printer为彩嘎嘎机系列	T02S1 T02S2/3/4	China/中国	Epson WF-C20750c 生产级墨仓式阵列复合机
wel-try gaga series printer为彩嘎嘎机系列	T02Q1 T02Q2/3/4	China/中国	Epson WF-C20600c 生产级墨仓式阵列复合机
wel-try gaga series printer为彩嘎嘎机系列	T8871/8871/8872/8873/8874	China/中国	WorkForce Enterprise WF-C20750 WorkForce Enterprise WF-M20590D4TW

CONTINUOUS INK SUPPLY SYSTEM FOR: :

WorkForce Enterprise WF-C20750
WorkForce Enterprise WF-M20590D4TW
WorkForce Enterprise WF-C21000 D4TW
WorkForce Enterprise WF-C20600 D4TW
WorkForce Enterprise WF-C20590
WorkForce Enterprise WF-C17590 D4TWF



WEL-TRY for Canon VII Series Inkjet Cartridge为彩佳能7代系列产品

Product Code为彩型号	OEM Product Code原装型号	Region地区	Description适用打印机
WEL-TRY-PGI280XXLPGBK	PGI-280XXLPGBK	NA	Canon PIXMA TR7520 (five colors) Canon PIXMA TR8520 (five colors) Canon PIXMA TS6120 (five colors) Canon PIXMA TS8120 (six colors) Canon PIXMA TS9120 (six colors) Canon PIXMA TS6220 (five colors) Canon PIXMA TS8220 (six colors) Canon PIXMA TS9521C (five colors) Canon PIXMA TS9520 (five colors) Canon PIXMA TS702 (five colors)
WEL-TRY-CLI281XXLBK	CLI-281XXLBK		
WEL-TRY-CLI281XXLC	CLI-281XXLC		
WEL-TRY-CLI281XXLM	CLI-281XXLM		
WEL-TRY-CLI281XXLY	CLI-281XXLY		
WEL-TRY-CLI281XXLPB	CLI-281XXLPB		
WEL-TRY-BCI380XLPGBK	BCI-380XLPGBK	JPN	Canon PIXUS TS8130 (six colors) Canon PIXUS TS6130 (five colors) Canon PIXUS TR8530 (five colors) Canon PIXUS TR7530 (five colors) Canon PIXUS TS8230 (six colors) Canon PIXUS TS6230 (five colors) Canon PIXUS TR9530 (five colors) Canon PIXUS TR703 (five colors) Canon PIXUS TS8330 (six colors) Canon PIXUS TS7330 (five colors) Canon PIXUS TS6330 (five colors) Canon PIXUS TR703a (five colors) Canon PIXUS TR8630a (five colors)
WEL-TRY-BCI381BK	BCI-381BK		
WEL-TRY-BCI381C	BCI-381C		
WEL-TRY-BCI381M	BCI-381M		
WEL-TRY-BCI381Y	BCI-381Y		
WEL-TRY-BCI381GY	BCI-381GY		
WEL-TRY-BCI381XLBK	BCI-381XLBK		
WEL-TRY-BCI381XLC	BCI-381XLC		
WEL-TRY-BCI381XLM	BCI-381XLM		
WEL-TRY-BCI381XLY	BCI-381XLY		
WEL-TRY-BCI381XLY	BCI-381XLY		
WEL-TRY-BCI381XLY	BCI-381XLY		
WEL-TRY-BCI381XLY	BCI-381XLY		
WEL-TRY-N10XLPGBK	XKI-N10XLPGBK	JPN	Canon PIXUS XK50 (six colors) Canon PIXUS XK60 (six colors) Canon PIXUS XK70 (six colors) Canon PIXUS XK80 (six colors) Canon PIXUS XK90 (six colors)
WEL-TRY-N11XLBK	XKI-N11XLBK		
WEL-TRY-N11XLC	XKI-N11XLC		
WEL-TRY-N11XLM	XKI-N11XLM		
WEL-TRY-N11XLY	XKI-N11XLY		
WEL-TRY-N11XLPB	XKI-N11XLPB		
WEL-TRY-XKIN20PGBK	XKI-N20PGBK	JPN	Canon PIXUS XK100 (five colors) Canon PIXUS XK500 (six colors) Canon PIXUS XK110 (five colors)
WEL-TRY-XKIN21BK	XKI-N21BK		
WEL-TRY-XKIN21C	XKI-N21C		
WEL-TRY-XKIN21M	XKI-N21M		
WEL-TRY-XKIN21Y	XKI-N21Y		
WEL-TRY-BCI301C	BCI-301C	JPN	Canon PIXUS TS7530 (five colors)
WEL-TRY-BCI301M	BCI-301M		
WEL-TRY-BCI301Y	BCI-301Y		
WEL-TRY-BCI301BK	BCI-301BK		
WEL-TRY-BCI300PGBK	BCI-300PGBK		
WEL-TRY-BCI331XLC	BCI-331XLC	JPN	Canon PIXUS TS8530(six colors)) Canon PIXUS TS8630(six colors))
WEL-TRY-BCI331XLM	BCI-331XLM		
WEL-TRY-BCI331XLY	BCI-331XLY		
WEL-TRY-BCI331XLBK	BCI-331XLBK		
WEL-TRY-BCI331XLY	BCI-331XLY		
WEL-TRY-BCI331XLBK	BCI-331XLBK		
WEL-TRY-BCI331XLY	BCI-331XLY		
WEL-TRY-BCI331XLBK	BCI-331XLBK		
WEL-TRY-BCI331XLY	BCI-331XLY		
WEL-TRY-BCI331XLBK	BCI-331XLBK		
WEL-TRY-BCI331XLY	BCI-331XLY		
WEL-TRY-PGI480XXLPGBK	PGI-480XXLPGBK	MEA	Canon PIXMA TS6140 (five colors) Canon PIXMA TS8140 (six colors) Canon PIXMA TS9140 (six colors) Canon PIXMA TR7540 (five colors) Canon PIXMA TR8540 (five colors) Canon PIXMA TS704 (five colors) Canon PIXMA TS8340 (six colors) Canon PIXMA TS6340 (five colors)
WEL-TRY-CLI481XXLBK	CLI-481XXLBK		
WEL-TRY-CLI481XXLC	CLI-481XXLC		
WEL-TRY-CLI481XXLM	CLI-481XXLM		
WEL-TRY-CLI481XXLY	CLI-481XXLY		
WEL-TRY-CLI481XXLPB	CLI-481XXLPB		
WEL-TRY-CLI481XXLPB	CLI-481XXLPB		
WEL-TRY-PGI580XXLPGBK	PGI-580XXLPGBK		Canon PIXMA TR7550 (five colors) Canon PIXMA TR8550 (five colors) Canon PIXMA TS6150 (five colors) Canon PIXMA TS6151 (five colors)
WEL-TRY-CLI581XXLBK	CLI-581XXLBK		

WEL-TRY-CLI581XXLC	CLI-581XXLC	EUR	Canon PIXMA TS8151 (five colors) Canon PIXMA TS8150 (five colors) Canon PIXMA TS8151 (six colors) Canon PIXMA TS8152 (six colors) Canon PIXMA TS9150 (six colors) Canon PIXMA TS9155 (six colors) Canon PIXMA TS6250 (five colors)
WEL-TRY-CLI581XXLM	CLI-581XXLM		
WEL-TRY-CLI581XXLY	CLI-581XXLY		
WEL-TRY-CLI581XXLPB	CLI-581XXLPB		
WEL-TRY-PGI680XXLPGBK	PGI-680XXLPGBK	AU	Canon PIXMA TR7560 (five colors) Canon PIXMA TR8560 (five colors) Canon PIXMA TS6160 (five colors) Canon PIXMA TS8160 (six colors) Canon PIXMA TS9160 (six colors) Canon PIXMA TS706 (five colors) Canon PIXMA TS6260 (five colors) Canon PIXMA TS8260 (six colors)
WEL-TRY-CLI681XXLBK	CLI-681XXLBK		
WEL-TRY-CLI681XXLC	CLI-681XXLC		
WEL-TRY-CLI681XXLM	CLI-681XXLM		
WEL-TRY-CLI681XXLY	CLI-681XXLY		
WEL-TRY-CLI681XXLPB	CLI-681XXLPB		
WEL-TRY-PGI780XXLPGBK	PGI-780XXLPGBK	AP	Canon PIXMA TR8570 (five colors) Canon PIXMA TS9170 (six colors) Canon PIXMA TS8170 (five colors) Canon PIXMA TS707 (six colors) Canon PIXMA TS8370 (six colors) Canon PIXMA TS6370 (five colors)
WEL-TRY-CLI781XXLBK	CLI-781XXLBK		
WEL-TRY-CLI781XLC	CLI-781XLC		
WEL-TRY-CLI781XLM	CLI-781XLM		
WEL-TRY-CLI781XLY	CLI-781XLY		
WEL-TRY-CLI781XLPB	CLI-781XLPB		
WEL-TRY-PGI880XXLPGBK	PGI-880XXLPGBK	CHN	Canon PIXMA TS9180 (six colors) Canon PIXMA TS8180 (six colors) Canon PIXMA TS6180 (five colors) Canon PIXMA TR8580 (five colors) Canon PIXMA TS8280 (six colors) Canon PIXMA TS6280 (five colors)
WEL-TRY-CLI881XXLBK	CLI-881XXLBK		
WEL-TRY-CLI881XLC	CLI-881XLC		
WEL-TRY-CLI881XLM	CLI-881XLM		
WEL-TRY-CLI881XLY	CLI-881XLY		
WEL-TRY-CLI881XLPB	CLI-881XLPB		
WEL-TRY-PGI980XXLPGBK	PGI-980XXLPGBK	KOR	Canon PIXMA TS8190 (six colors) Canon PIXMA TS8195 (six colors)
WEL-TRY-CLI981XXLBK	CLI-981XXLBK		
WEL-TRY-CLI981XLC	CLI-981XLC		
WEL-TRY-CLI981XLM	CLI-981XLM		
WEL-TRY-CLI981XLY	CLI-981XLY		
WEL-TRY-CLI981XLPB	CLI-981XLPB		

WEL-TRY product photos for canon vii series product为彩佳能7代产品个图片



WEL-TRY for Canon VI Series Inkjet Cartridge为彩佳能6代系列产品

Product Code为彩型号	OEM Product Code原装型号	Region地区	Description适用打印机		
WEL-TRY-PGI170PGBK	PGI-170PGBK	LA	Canon PIXMA MG7710 (six colors including GY) Canon PIXMA MG6810 (five colors) Canon PIXMA MG5710 (five colors)		
WEL-TRY-CLI171BK	CLI-171BK				
WEL-TRY-CLI171C	CLI-171C				
WEL-TRY-CLI171M	CLI-171M				
WEL-TRY-CLI171Y	CLI-171Y				
WEL-TRY-CLI171GY	CLI-171GY				
WEL-TRY-PGI170PGBKXL	PGI-170PGBKXL				
WEL-TRY-CLI171BKXL	CLI-171BKXL				
WEL-TRY-CLI171CXL	CLI-171CXL				
WEL-TRY-CLI171MXL	CLI-171MXL				
WEL-TRY-CLI171YXL	CLI-171YXL				
WEL-TRY-CLI171GYXL	CLI-171GYXL				
WEL-TRY-PGI270PGBK	PGI-270PGBK			NA	Canon PIXMA MG5720 (five colors) Canon PIXMA MG5721 (five colors) Canon PIXMA MG5722 (five colors) Canon PIXMA MG6820 (five colors) Canon PIXMA MG6821 (five colors) Canon PIXMA MG6822 (five colors) Canon PIXMA MG7720 (six colors including GY) Canon PIXMA TS9020/TS8020 (six colors including GY) Canon PIXMA TS6020/TS5020 (five colors)
WEL-TRY-CLI271BK	CLI-271BK				
WEL-TRY-CLI271C	CLI-271C				
WEL-TRY-CLI271M	CLI-271M				
WEL-TRY-CLI271Y	CLI-271Y				
WEL-TRY-CLI271GY	CLI-271GY				
WEL-TRY-PGI270PGBKXL	PGI-270PGBKXL				
WEL-TRY-CLI271BKXL	CLI-271BKXL				
WEL-TRY-CLI271CXL	CLI-271CXL				
WEL-TRY-CLI271MXL	CLI-271MXL				
WEL-TRY-CLI271YXL	CLI-271YXL				
WEL-TRY-CLI271GYXL	CLI-271GYXL				
WEL-TRY-BCI370PGBK	BCI-370PGBK				
WEL-TRY-BCI371BK	BCI-371BK				
WEL-TRY-BCI371C	BCI-371C				
WEL-TRY-BCI371M	BCI-371M				
WEL-TRY-BCI371Y	BCI-371Y				

WEL-TRY-BCI371GY	BCI-371GY	JPN	Canon PIXUS MG7730 (six colors including GY) Canon PIXUS MG6930 (six colors including GY) Canon PIXUS MG5730 (five colors) Canon PIXUS TS9030/TS8030 (six colors including GY) Canon PIXUS TS6030/TS5030 (five colors)		
WEL-TRY-BCI370PGBKXL	BCI-370PGBKXL				
WEL-TRY-BCI371BKXL	BCI-371BKXL				
WEL-TRY-BCI371CXL	BCI-371CXL				
WEL-TRY-BCI371MXL	BCI-371MXL				
WEL-TRY-BCI371YXL	BCI-371YXL				
WEL-TRY-BCI371GYXL	BCI-371GYXL				
WEL-TRY-PGI470PGBK	PGI-470PGBK			MEA	Canon PIXMA MG7740 (six colors including GY) Canon PIXMA MG6840 (five colors) Canon PIXMA MG5740 (five colors)
WEL-TRY-CLI471BK	CLI-471BK				
WEL-TRY-CLI471C	CLI-471C				
WEL-TRY-CLI471M	CLI-471M				
WEL-TRY-CLI471Y	CLI-471Y				
WEL-TRY-CLI471GY	CLI-471GY				
WEL-TRY-PGI470PGBKXL	PGI-470PGBKXL				
WEL-TRY-CLI471BKXL	CLI-471BKXL				
WEL-TRY-CLI471CXL	CLI-471CXL				
WEL-TRY-CLI471MXL	CLI-471MXL				
WEL-TRY-CLI471YXL	CLI-471YXL				
WEL-TRY-CLI471GYXL	CLI-471GYXL				
WEL-TRY-PGI570PGBK	PGI-570PGBK	EUR	Canon PIXMA MG5750 (five colors) Canon PIXMA MG5751 (five colors) Canon PIXMA MG5752 (five colors) Canon PIXMA MG5753 (five colors) Canon PIXMA MG6850 (five colors) Canon PIXMA MG6851 (five colors) Canon PIXMA MG6852 (five colors) Canon PIXMA MG6853 (five colors) Canon PIXMA MG7750 (six colors including GY) Canon PIXMA MG7751 (six colors including GY) Canon PIXMA MG7752 (six colors including GY) Canon PIXMA MG7753 (six colors including GY) Canon PIXMA TS9050/9055/8050/8051/8052/8053 (six colors including GY) Canon PIXMA TS6050/6051/6052/5050/5051/5052/5053 (five colors)		
WEL-TRY-CLI571BK	CLI-571BK				
WEL-TRY-CLI571C	CLI-571C				
WEL-TRY-CLI571M	CLI-571M				
WEL-TRY-CLI571Y	CLI-571Y				
WEL-TRY-CLI571GY	CLI-571GY				
WEL-TRY-PGI570PGBKXL	PGI-570PGBKXL				
WEL-TRY-CLI571BKXL	CLI-571BKXL				
WEL-TRY-CLI571CXL	CLI-571CXL				
WEL-TRY-CLI571MXL	CLI-571MXL				
WEL-TRY-CLI571YXL	CLI-571YXL				
WEL-TRY-CLI571GYXL	CLI-571GYXL				

WEL-TRY-PGI670PGBK	PGI-670PGBK	AUS	<p>Canon PIXMA MG7760 (six colors including GY) Canon PIXMA MG7765 (six colors including GY) Canon PIXMA MG7766 (six colors including GY) Canon PIXMA MG6860 (five colors) Canon PIXMA MG5760 (five colors) Canon PIXMA MG6865 (five colors) Canon PIXMA MG5765 (five colors) Canon PIXMA TS6060/TS5060 (five colors)</p>		
WEL-TRY-CLI671BK	CLI-671BK				
WEL-TRY-CLI671C	CLI-671C				
WEL-TRY-CLI671M	CLI-671M				
WEL-TRY-CLI671Y	CLI-671Y				
WEL-TRY-CLI671GY	CLI-671GY				
WEL-TRY-PGI670PGBKXL	PGI-670PGBKXL				
WEL-TRY-CLI671BKXL	CLI-671BKXL				
WEL-TRY-CLI671CXL	CLI-671CXL				
WEL-TRY-CLI671MXL	CLI-671MXL				
WEL-TRY-CLI671YXL	CLI-671YXL				
WEL-TRY-CLI671GYXL	CLI-671GYXL				
WEL-TRY-PGI770PGBK	PGI-770PGBK			AP	<p>Canon PIXMA MG7770 (six colors including GY) Canon PIXMA MG6870 (five colors) Canon PIXMA MG5770 (five colors)</p>
WEL-TRY-CLI771BK	CLI-771BK				
WEL-TRY-CLI771C	CLI-771C				
WEL-TRY-CLI771M	CLI-771M				
WEL-TRY-CLI771Y	CLI-771Y				
WEL-TRY-CLI771GY	CLI-771GY				
WEL-TRY-PGI770PGBKXL	PGI-770PGBKXL				
WEL-TRY-CLI771BKXL	CLI-771BKXL				
WEL-TRY-CLI771CXL	CLI-771CXL				
WEL-TRY-CLI771MXL	CLI-771MXL				
WEL-TRY-CLI771YXL	CLI-771YXL				
WEL-TRY-CLI771GYXL	CLI-771GYXL				
WEL-TRY-PGI870PGBK	PGI-870PGBK	CHN	<p>Canon PIXMA MG7780 (six colors including GY) Canon PIXMA MG6880 (five colors) Canon PIXMA MG5780 (five colors) Canon PIXMA TS9080/TS8080 (six colors including GY) Canon PIXMA TS6080/TS5080 (five colors)</p>		
WEL-TRY-CLI871BK	CLI-871BK				
WEL-TRY-CLI871C	CLI-871C				
WEL-TRY-CLI871M	CLI-871M				
WEL-TRY-CLI871Y	CLI-871Y				
WEL-TRY-CLI871GY	CLI-871GY				
WEL-TRY-PGI870PGBKXL	PGI-870PGBKXL				

WEL-TRY-CLI871BKXL	CLI-871BKXL		
WEL-TRY-CLI871CXL	CLI-871CXL		
WEL-TRY-CLI871MXL	CLI-871MXL		
WEL-TRY-CLI871YXL	CLI-871YXL		
WEL-TRY-CLI871GYXL	CLI-871GYXL		
WEL-TRY-PGI970PGBK	PGI-970PGBK	KOR	Canon PIXMA MG7790 (six colors including GY) Canon PIXMA MG5795 (five colors) Canon PIXMA MG5790 (five colors) Canon PIXMA TS5090 (five colors)
WEL-TRY-CLI971BK	CLI-971BK		
WEL-TRY-CLI971C	CLI-971C		
WEL-TRY-CLI971M	CLI-971M		
WEL-TRY-CLI971Y	CLI-971Y		
WEL-TRY-CLI971GY	CLI-971GY		
WEL-TRY-PGI970PGBKXL	PGI-970PGBKXL		
WEL-TRY-CLI971BKXL	CLI-971BKXL		
WEL-TRY-CLI971CXL	CLI-971CXL		
WEL-TRY-CLI971MXL	CLI-971MXL		
WEL-TRY-CLI971YXL	CLI-971YXL		
WEL-TRY-CLI971GYXL	CLI-971GYXL		



WEL-TRY For Canon V Series Inkjet Cartridge 为彩佳能5代系列产品

Product Code	OEM Product Code	Region	Description	
WEL-TRY-PGI2100BK	PGI2100BK	LA	Canon MAXIFY MB5310/IB4010 (LA)	
WEL-TRY-PGI2100C	PGI2100C			
WEL-TRY-PGI2100M	PGI2100M			
WEL-TRY-PGI2100Y	PGI2100Y			
WEL-TRY-PGI2100BKXL	PGI2100BKXL			
WEL-TRY-PGI2100CXL	PGI2100CXL			
WEL-TRY-PGI2100MXL	PGI2100MXL			
WEL-TRY-PGI2100YXL	PGI2100YXL			
WEL-TRY-PGI1100BK	PGI1100BK			Canon MAXIFY MB2010 (LA)
WEL-TRY-PGI1100C	PGI1100C			
WEL-TRY-PGI1100M	PGI1100M			
WEL-TRY-PGI1100Y	PGI1100Y			
WEL-TRY-PGI1100BKXL	PGI1100BKXL			
WEL-TRY-PGI1100CXL	PGI1100CXL			
WEL-TRY-PGI1100MXL	PGI1100MXL			
WEL-TRY-PGI1100YXL	PGI1100YXL			
WEL-TRY-PGI1200BK	PGI1200BK		NA	
WEL-TRY-PGI1200C	PGI1200C			
WEL-TRY-PGI1200M	PGI1200M			
WEL-TRY-PGI1200Y	PGI1200Y			
WEL-TRY-PGI1200BKXL	PGI1200BKXL			
WEL-TRY-PGI1200CXL	PGI1200CXL			
WEL-TRY-PGI1200MXL	PGI1200MXL			
WEL-TRY-PGI1200YXL	PGI1200YXL			
WEL-TRY-PGI2200BK	PGI2200BK	Canon MAXIFY MB5020/MB5320/iB4020/MB5120/MB5420/iB4120 (USA)		
WEL-TRY-PGI2200C	PGI2200C			
WEL-TRY-PGI2200M	PGI2200M			
WEL-TRY-PGI2200Y	PGI2200Y			
WEL-TRY-PGI2200BKXL	PGI2200BKXL			
WEL-TRY-PGI2200CXL	PGI2200CXL			
WEL-TRY-PGI2200MXL	PGI2200MXL			
WEL-TRY-PGI2200YXL	PGI2200YXL			
WEL-TRY-PGI1300BKXL	PGI1300BKXL			JPN
WEL-TRY-PGI1300CXL	PGI1300CXL			
WEL-TRY-PGI1300MXL	PGI1300MXL			
WEL-TRY-PGI1300YXL	PGI1300YXL			
WEL-TRY-PGI1300BK	PGI1300BK			
WEL-TRY-PGI1300C	PGI1300C			
WEL-TRY-PGI1300M	PGI1300M			
WEL-TRY-PGI1300Y	PGI1300Y			
WEL-TRY-PGI2300BKXL	PGI2300BKXL	Canon MAXIFY MB5030/MB5330/iB4030/MB5130/MB5430/iB4130(JA)		
WEL-TRY-PGI2300CXL	PGI2300CXL			
WEL-TRY-PGI2300MXL	PGI2300MXL			
WEL-TRY-PGI2300YXL	PGI2300YXL			
WEL-TRY-PGI2300BK	PGI2300BK			
WEL-TRY-PGI2300C	PGI2300C			
WEL-TRY-PGI2300M	PGI2300M			

WEL-TRY-PGI2300Y	PGI2300Y		
WEL-TRY-PGI1400BKXL	PGI1400BKXL	MEA	Canon MAXIFY MB2340/MB2040/MB2140/MB2740 (ME)
WEL-TRY-PGI1400CXL	PGI1400CXL		
WEL-TRY-PGI1400MXL	PGI1400MXL		
WEL-TRY-PGI1400YXL	PGI1400YXL		
WEL-TRY-PGI2400BKXL	PGI2400BKXL		Canon MAXIFY iB4040/MB5040/MB5340/MB5140/MB5440/IB4140 (ME)
WEL-TRY-PGI2400CXL	PGI2400CXL		
WEL-TRY-PGI2400MXL	PGI2400MXL		
WEL-TRY-PGI2400YXL	PGI2400YXL		
WEL-TRY-PGI1500BKXL	PGI1500BKXL	EUR	Canon MAXIFY MB2050/MB2350/MB2150/MB2750 (EUR)
WEL-TRY-PGI1500CXL	PGI1500CXL		
WEL-TRY-PGI1500MXL	PGI1500MXL		
WEL-TRY-PGI1500YXL	PGI1500YXL		
WEL-TRY-PGI2500BKXL	PGI2500BKXL		Canon MAXIFY IB4050/MB5050/MB5350/MB5150/MB5450/IB4150 (EUR)
WEL-TRY-PGI2500CXL	PGI2500CXL		
WEL-TRY-PGI2500MXL	PGI2500MXL		
WEL-TRY-PGI2500YXL	PGI2500YXL		
WEL-TRY-PGI1600BK	PGI1600BK	AUS	Canon MAXIFY iB4060/MB2060/MB2360 (AU)
WEL-TRY-PGI1600C	PGI1600C		
WEL-TRY-PGI1600M	PGI1600M		
WEL-TRY-PGI1600Y	PGI1600Y		
WEL-TRY-PGI1600BKXL	PGI1600BKXL		
WEL-TRY-PGI1600CXL	PGI1600CXL		
WEL-TRY-PGI1600MXL	PGI1600MXL		
WEL-TRY-PGI1600YXL	PGI1600YXL		
WEL-TRY-PGI2600BK	PGI2600BK		Canon MAXIFY MB5060/MB5360 (AU)
WEL-TRY-PGI2600C	PGI2600C		
WEL-TRY-PGI2600M	PGI2600M		
WEL-TRY-PGI2600Y	PGI2600Y		
WEL-TRY-PGI2600BKXL	PGI2600BKXL		
WEL-TRY-PGI2600CXL	PGI2600CXL		
WEL-TRY-PGI2600MXL	PGI2600MXL		
WEL-TRY-PGI2600YXL	PGI2600YXL		
WEL-TRY-PGI2700BK	PGI-2700BK	AP	Canon MAXIFY MB5370 (AP) Canon MAXIFY MB5070 Canon MAXIFY iB4070/MB5170/MB5470/IB4170
WEL-TRY-PGI2700C	PGI-2700C		
WEL-TRY-PGI2700M	PGI-2700M		
WEL-TRY-PGI2700Y	PGI-2700Y		
WEL-TRY-PGI2700BKXL	PGI-2700XLBK		
WEL-TRY-PGI2700CXL	PGI-2700XLC		
WEL-TRY-PGI2700MXL	PGI-2700XLM		
WEL-TRY-PGI2700YXL	PGI-2700XLY		
WEL-TRY-PGI2800BK	PGI-2800BK	CHN	Canon MAXIFY MB5080 (CHN) Canon MAXIFY iB4080/MB5180/MB5480/IB4180
WEL-TRY-PGI2800C	PGI-2800C		
WEL-TRY-PGI2800M	PGI-2800M		
WEL-TRY-PGI2800Y	PGI-2800Y		
WEL-TRY-PGI2800BKXL	PGI-2800XLBK		
WEL-TRY-PGI2800CXL	PGI-2800XLC		
WEL-TRY-PGI2800MXL	PGI-2800XLM		
WEL-TRY-PGI2800YXL	PGI-2800XLY		


WEL-TRY-PGI1900BKXL	PGI-1900XLBK	KOR	Canon MB2090 Canon MB2390 (KOR)
WEL-TRY-PGI1900CXL COMING SOON!	PGI-1900XLC		
WEL-TRY-PGI1900MXL COMING SOON!	PGI-1900XLM		
WEL-TRY-PGI1900YXL COMING SOON!	PGI-1900XLY		
WEL-TRY-PGI1900BK	PGI-1900BK		
WEL-TRY-PGI1900C	PGI-1900C		
WEL-TRY-PGI1900M	PGI-1900M		
WEL-TRY-PGI1900Y	PGI-1900Y		
WEL-TRY-PGI2900BK	PGI-2900BK		Canon MAXIFY iB4090/MB5090/MB5390 (KOR)
WEL-TRY-PGI2900C	PGI-2900C		
WEL-TRY-PGI2900M	PGI-2900M		
WEL-TRY-PGI2900Y	PGI-2900Y		
WEL-TRY-PGI2900BKXL	PGI2900BKXL		
WEL-TRY-PGI2900CXL	PGI2900CXL		
WEL-TRY-PGI2900MXL	PGI2900MXL		
WEL-TRY-PGI2900YXL	PGI2900YXL		

1100
1200
1300
1400
1500
1600
1700
1800
1900



Refillable inkjet cartridge

2100
2200
2300
2400
2500
2600
2700
2800
2900



WEL-TRY®

WEL-TRY for Canon IV Series Inkjet Cartridge 为彩佳能4代系列产品

Product Code	OEM Product Code	Region	Description
WEL-TRY-PGI150PGBKXL	PGI-150PGBK XL	LA	Canon PIXMA IP7210 Canon PIXMA MG5410 Canon PIXMA MX921
WEL-TRY-CLI151BKXL	CLI-151BK XL		
WEL-TRY-CLI151CXL	CLI-151C XL		
WEL-TRY-CLI151MXL	CLI-151M XL		
WEL-TRY-CLI151YXL	CLI-151Y XL		
WEL-TRY-CLI151GYXL	CLI-151GY XL		
WEL-TRY-PGI250PGBK	PGI-250PGBK	NA	Canon PIXMA ip7220/8720 Canon PIXMA MG5420 Canon PIXMA MX922 Canon PIXMA MX722 Canon PIXMA IX6820 Canon MG5520/MG5620/MG6420/MG6620
WEL-TRY-CLI251BK	CLI-251BK		
WEL-TRY-CLI251C	CLI-251C		
WEL-TRY-CLI251M	CLI-251M		
WEL-TRY-CLI251Y	CLI-251Y		
WEL-TRY-CLI251GY	CLI-251GY		
WEL-TRY-PGI250PGBKXL	PGI-250PGBK XL		
WEL-TRY-CLI251BKXL	CLI-251BK XL		
WEL-TRY-CLI251CXL	CLI-251C XL		
WEL-TRY-CLI251MXL	CLI-251M XL		
WEL-TRY-CLI251YXL	CLI-251Y XL		
WEL-TRY-CLI251GYXL	CLI-251GY XL		
WEL-TRY-PGI255PGBKXXL	PGI-255PGBK XXL		
WEL-TRY-BCI350PGBKXL	BCI-350PGBK XL		
WEL-TRY-BCI351BKXL	BCI-351BK XL	JPN	Canon PIXUS ip7230/ip8730 Canon PIXUS MG5430/MG5630 Canon PIXUS MX923 Canon PIXUS MX723 Canon PIXUS MG5530/IX6830
WEL-TRY-BCI351CXL	BCI-351C XL		
WEL-TRY-BCI351MXL	BCI-351M XL		
WEL-TRY-BCI351YXL	BCI-351Y XL		
WEL-TRY-BCI351GYXL	BCI-351GY XL		
WEL-TRY-BCI355PGBKXXL	BCI-355PGBK XXL		
WEL-TRY-PGI450PGBK	PGI-450PGBK	MEA	Canon PIXMA ip7240 Canon PIXMA MG5440
WEL-TRY-CLI451BK	CLI-451BK		
WEL-TRY-CLI451C	CLI-451C		
WEL-TRY-CLI451M	CLI-451M		
WEL-TRY-CLI451Y	CLI-451Y		
WEL-TRY-CLI451GY	CLI-451GY		
WEL-TRY-PGI450PGBKXL	PGI-450PGBK XL		
WEL-TRY-CLI451BKXL	CLI-451BK XL		
WEL-TRY-CLI451CXL	CLI-451C XL		
WEL-TRY-CLI451MXL	CLI-451M XL		
WEL-TRY-CLI451YXL	CLI-451Y XL		
WEL-TRY-CLI451GYXL	CLI-451GY XL		
WEL-TRY-PGI550PGBK	PGI-550PGBK	EUR	Canon PIXMA ip7250 /IP8750 Canon PIXMA MG5450 Canon PIXMA MX725 Canon PIXMA MX925 Canon PIXMA MG6450/MG5550/IX6850/MG5650
WEL-TRY-CLI551BK	CLI-551BK		
WEL-TRY-CLI551C	CLI-551C		
WEL-TRY-CLI551M	CLI-551M		
WEL-TRY-CLI551Y	CLI-551Y		
WEL-TRY-CLI551GY	CLI-551GY		
WEL-TRY-PGI550PGBKXL	PGI-550PGBK XL		

WEL-TRY-CLI551BKXL	CLI-551BK XL		Canon PIXMA ip7250/IP8750 Canon PIXMA MG5450 Canon PIXMA MX725 Canon PIXMA MX925 Canon PIXMA MG6450/MG5550/IX6850/MG5650
WEL-TRY-CLI551CXL	CLI-551C XL		Canon PIXMA MG6350/MG7150
WEL-TRY-CLI551MXL	CLI-551M XL		Canon PIXMA MX725/MX925
WEL-TRY-CLI551YXL	CLI-551Y XL		
WEL-TRY-CLI551GYXL	CLI-551GY XL		
WEL-TRY-PGI555PGBKXXL	PGI-555PGBK XXL		
WEL-TRY-PGI650PGBKXL	PGI-650PGBK XL	AUS	Canon PIXMA iP7260 Canon PIXMA MG5460 Canon PIXMA MX726 Canon PIXMA MX926 Canon PIXMA IX6860/IP8760/MG5560
WEL-TRY-CLI651BKXL	CLI-651BK XL		Canon PIXMA MG6360
WEL-TRY-CLI651CXL	CLI-651C XL		Canon PIXMA MX926
WEL-TRY-CLI651MXL	CLI-651M XL		
WEL-TRY-CLI651YXL	CLI-651Y XL		
WEL-TRY-CLI651GYXL	CLI-651GY XL		
WEL-TRY-PGI655PGBKXXL	PGI-655PGBK XXL		
WEL-TRY-PGI750PGBKXL	PGI-750PGBK XL	AP	Canon PIXMA ip7270 Canon PIXMA MG5470 Canon PIXMA MX727 Canon PIXMA MX927 Canon PIXMA MG6470/MG5570/IX6770/MG6670 Canon PIXMA MG7570/IX6870
WEL-TRY-CLI751BKXL	CLI-751BK XL		Canon PIXMA MG6370/MG7570
WEL-TRY-CLI751CXL	CLI-751C XL		Canon PIXMA MX727/MX927
WEL-TRY-CLI751MXL	CLI-751M XL		
WEL-TRY-CLI751YXL	CLI-751Y XL		
WEL-TRY-CLI751GYXL	CLI-751GY XL		
WEL-TRY-PGI755PGBKXXL	PGI-755PGBK XXL		
WEL-TRY-PGI850PGBKXL	PGI-850PGBK XL	CHN	Canon PIXMA ip7280 Canon PIXMA MG5480 Canon PIXMA IX6880/MG5680/MG6680/MG6480/MG5580/IX6780
WEL-TRY-CLI851BKXL	CLI-851BK XL		Canon PIXMA MG6380/MG7180/MG7580
WEL-TRY-CLI851CXL	CLI-851C XL		Canon PIXMA MX728/MX928
WEL-TRY-CLI851MXL	CLI-851M XL		
WEL-TRY-CLI851YXL	CLI-851Y XL		
WEL-TRY-CLI851GYXL	CLI-851GY XL		
WEL-TRY-PGI855PGBKXXL	PGI-855PGBK XXL		



WEL-TRY for Canon III Series Inkjet Cartridge为彩佳能3代产品

Product Code	OEM Product Code	Region	Description
WEL-TRY-PGI125PGBK	PGI125PGBK	LA	Canon PIXMA MG6110/5210 Canon PIXMA IP4810 Canon PIXMA IX6510
WEL-TRY-CLI126BK	CLI126BK		
WEL-TRY-CLI126C	CLI126C		
WEL-TRY-CLI126M	CLI126M		
WEL-TRY-CLI126Y	CLI126Y		
WEL-TRY-CLI126GY	CLI126GY		
WEL-TRY-PGI225PGBK	PGI225PGBK	NA	Canon PIXMA MG8120/6120/5220/5120/5210/5320 Canon PIXMA IP4820/4810/4920 Canon PIXMA IX6520 Canon PIXMA MX882
WEL-TRY-CLI226BK	CLI226BK		
WEL-TRY-CLI226C	CLI226C		
WEL-TRY-CLI226M	CLI226M		
WEL-TRY-CLI226Y	CLI226Y		
WEL-TRY-CLI226GY	CLI226GY		
WEL-TRY-BCI325PGBK	BCI325PGBK	JPN	Canon PIXUS MG8130/6130/5230/5130/MG6230/MG8230/MG5330 Canon PIXUS IP4830/IP4930 Canon PIXUS IX6530 Canon PIXUS MX883/MX893
WEL-TRY-BCI326BK	BCI326BK		
WEL-TRY-BCI326C	BCI326C		
WEL-TRY-BCI326M	BCI326M		
WEL-TRY-BCI326Y	BCI326Y		
WEL-TRY-BCI326GY	BCI326GY		
WEL-TRY-PGI425PGBK	PGI425PGBK	MEA	Canon PIXMA MG8140/6140/5240 Canon PIXMA IP4840 Canon PIXMA IX6540 Canon PIXMA MX884
WEL-TRY-CLI426BK	CLI426BK		
WEL-TRY-CLI426C	CLI426C		
WEL-TRY-CLI426M	CLI426M		
WEL-TRY-CLI426Y	CLI426Y		
WEL-TRY-CLI426GY	CLI426GY		
WEL-TRY-PGI525PGBK	PGI525PGBK	EUR	Canon PIXMA MG8150/6150/5250/MG8250 Canon PIXMA IP4850 Canon PIXMA IX6550 Canon PIXMA MX885/MX895/MX715
WEL-TRY-CLI526BK	CLI526BK		
WEL-TRY-CLI526C	CLI526C		
WEL-TRY-CLI526M	CLI526M		
WEL-TRY-CLI526Y	CLI526Y		
WEL-TRY-CLI526GY	CLI526GY		

WEL-TRY for Canon II Series Inkjet Cartridge为彩佳能2代系列产品

Product Code	OEM Product Code	Region	Description
WEL-TRY-CLI221BK	CLI-221BK	NA	Canon PIXMA iP3600/iP4600 Canon PIXMA MP540/MP620/MP630/MP980 (USA) Canon PIXMA MX860/MX870
WEL-TRY-CLI221C	CLI-221C		
WEL-TRY-CLI221M	CLI-221M		
WEL-TRY-CLI221Y	CLI-221Y		
WEL-TRY-PGI220BK	PGI-220BK		
WEL-TRY-CLI221GY	CLI-221GY		Canon PIXMA MP980 (USA)
WEL-TRY-BCI321BK	BCI-321BK	JPN	Canon PIXUS iP3600/iP4600 (JP) Canon PIXUS MP540/MP620/MP630/MP980/MX860/MX870
WEL-TRY-BCI321C	BCI-321C		
WEL-TRY-BCI321M	BCI-321M		
WEL-TRY-BCI321Y	BCI-321Y		
WEL-TRY-BCI320PGBK	BCI-320PGBK		
WEL-TRY-BCI321GY	BCI-321GY		Canon PIXUS MP980 (JP)
WEL-TRY-CLI521BK	CLI-521BK	EUR	Canon PIXMA iP3600/iP4600 Canon PIXMA MP540/MP620/MP630/MP980 (EUR) Canon PIXMA MX860/MX870
WEL-TRY-CLI521C	CLI-521C		
WEL-TRY-CLI521M	CLI-521M		
WEL-TRY-CLI521Y	CLI-521Y		
WEL-TRY-PGI520BK	PGI-520BK		
WEL-TRY-CLI521GY	CLI-521GY		Canon PIXMA MP980 (EUR)
WEL-TRY-CLI821BK	CLI-821BK	CHN	Canon PIXMA iP3680/iP4680 Canon PIXMA MP545/MP628/MP988 (CHN) Canon PIXMA MX638/MX868/MX876
WEL-TRY-CLI821C	CLI-821C		
WEL-TRY-CLI821M	CLI-821M		
WEL-TRY-CLI821Y	CLI-821Y		
WEL-TRY-PGI820BK	PGI-820BK		
WEL-TRY-CLI821GY	CLI-821GY		Canon PIXMA MP988 (CHN)



WEL-TRY for Canon I Series Inkjet Cartridge 为彩佳能1代系列产品

Product Code	OEM Product Code	Region	Description
WEL-TRY-PGI5BK	PGI-5BK	WW (ex.JPN)	Canon PIXMA IP3300/IP4200/IP4300/IP4500 Canon PIXMA IX4000/IX5000 Canon PIXMA MP970
WEL-TRY-CLI8BK	CLI-8BK		Canon PIXMA IP4200/IP4500/IP4300/IP5300 Canon PIXMA Pro9000
WEL-TRY-CLI8C	CLI-8C		
WEL-TRY-CLI8M	CLI-8M		
WEL-TRY-CLI8Y	CLI-8Y		
WEL-TRY-CLI8PC	CLI-8PC		
WEL-TRY-CLI8PM	CLI-8PM		
WEL-TRY-CLI8R	CLI-8R		
WEL-TRY-CLI8G	CLI-8G		
WEL-TRY-BCI9BK	BCI-9PGBK	JPN	
WEL-TRY-BCI7BK	BCI-7eBK		Canon PIXUS MP950/MP960/MP970/MP900 Canon PIXUS PRO9000 Canon PIXUS ip8600/ip9910
WEL-TRY-BCI7C	BCI-7eC		
WEL-TRY-BCI7M	BCI-7eM		
WEL-TRY-BCI7Y	BCI-7eY		
WEL-TRY-BCI7PC	BCI-7ePC		
WEL-TRY-BCI7PM	BCI-7ePM		
WEL-TRY-BCI7R	BCI-7eR		
WEL-TRY-BCI7G	BCI-7eG		
WEL-TRY-PGI7BK	PGI-7BK	WW (ex.JPN)	
WEL-TRY-PGI9PBK	PGI-9PBK		Canon PIXMA ix7000/MX7600 Canon PIXMA Pro9500
WEL-TRY-PGI9C	PGI-9C		
WEL-TRY-PGI9M	PGI-9M		
WEL-TRY-PGI9Y	PGI-9Y		
WEL-TRY-PGI9R	PGI-9R		
WEL-TRY-PGI9MBK	PGI-9MBK		
WEL-TRY-PGI9G	PGI-9G		
WEL-TRY-PGI9PM	PGI-9PM		
WEL-TRY-PGI9PC	PGI-9PC		
WEL-TRY-PGI9GY	PGI-9GY		
WEL-TRY-BCI19BK	BCI-19BK		



for Canon Wide Format Cartridge

Product Code	OEM Product Code	Region	Description
WEL-TRY-PFI102MK	0894B001	WW	Canon imagePROGRAF 500/510 Canon imagePROGRAF 600/605/610 Canon imagePROGRAF 700/710/720/750/755 Canon imagePROGRAF 605/610/655
WEL-TRY-PFI102K	0985B001		
WEL-TRY-PFI102C	0896B001		
WEL-TRY-PFI102M	0897B001		
WEL-TRY-PFI102Y	0898B001		
WEL-TRY-1431BK	BCI-1431BK		Canon W6200/6400
WEL-TRY-1431C	BCI-1431C		
WEL-TRY-1431M	BCI-1431M		
WEL-TRY-1431Y	BCI-1431Y		
WEL-TRY-1431LC	BCI-1431LC		
WEL-TRY-1431LM	BCI-1431LM		



BCI-1401 for Canon: W6400 Dye/7250 (BK/C/M/Y/PC/PM/MBK).
BCI-1411 for Canon: W7200/8200/8400 Dye (BK/C/M/Y/PC/PM/MBK).
BCI-1421 for Canon: W8200 Pg/8400 Pg (BK/C/M/Y/PC/PM).
BCI-1431 for Canon: W6200/6400 Pg (BK/C/M/Y/PC/PM).
BCI-1441 for Canon: W8400 (MBK/Y).
BCI-1451 for Canon: W6400 (MBK/Y).



Refillable inkjet cartridge

Compatible inkjet cartridge

PFI-301, PFI-302, PFI-701, PFI-702 for Canon: iPF8000, iPF8100, iPF8110, iPF8300, iPF8310, iPF9000, iPF9100, iPF9110 (MB, BK, C, M, Y, PC, PM, R, G, B, GY, PGY)
 iPF8000s, iPF9000s, iPF8010s, iPF9010s (MB, BK, C, M, Y, PC, PM, GY)

PFI-303, PFI-703 for Canon: iPF810, iPF815, iPF820, iPF825 (MB, BK, C, M, Y)

PFI-304, PFI-704 for Canon: iPF8300, iPF8310 (MB, BK, C, M, Y, PC, PM, R, G, B, GY, PGY)

PFI-306, PFI-706 for Canon: iPF8400, iPF8400s, iPF9400, iPF9400s, iPF9410, iPF9410s.



(250ML)

Refillable/
compatible
inkjet cartridge.


PFI-101, PFI-103 for : iPF5000, iPF5100, iPF6100, iPF6200, iPF6200s, iPF6000s, iPF720, iPFX100.
 (MB, BK, C, M, Y, PC, PM, R, G, B, GY, PGY)

PFI-102, PFI-104 for Canon:
 iPF500, iPF510, iPF600, iPF605, iPF610, iPF650, iPF655, iPF700, iPF710, iPF720, iPF750, iPF755, iPF760, iPF765.
 (MB, BK, C, M, Y)

PFI-105 for Canon: iPF6300, iPF6350. (MB, BK, C, M, Y, PC, PM, R, G, B, GY, PGY).

WEL-TRY for Ricoh Series Inkjet Cartridge为彩理光系列产品




Product Code	OEM Product Code	Region	Description
WEL-TRY-GC21BKH	GC21BKH	/	Ricoh GX7000 Ricoh GX5050N
WEL-TRY-GC21CH	GC21CH	/	
WEL-TRY-GC21MH	GC21MH	/	
WEL-TRY-GC21YH	GC21YH	/	
WEL-TRY-GC21BK	GC21BK	/	Ricoh GX7000 Ricoh GX5050 Ricoh GX3000SF Ricoh GX3000S Ricoh GX3000 Ricoh GX2500
WEL-TRY-GC21C	GC21C	/	
WEL-TRY-GC21M	GC21M	/	
WEL-TRY-GC21Y	GC21Y	/	
WEL-TRY-GC31HBK	GC31HBK	/	
WEL-TRY-GC31HC	GC31HC	/	
WEL-TRY-GC31HM	GC31HM	/	Ricoh GX e5550/e5550n Ricoh Ipsio GX e5500
WEL-TRY-GC31HY	GC31HY	/	
WEL-TRY-GC31BK	GC31BK	/	
WEL-TRY-GC31C	GC31C	/	
WEL-TRY-GC31M	GC31M	/	
WEL-TRY-GC31Y	GC31Y	/	
WEL-TRY-GC31MFC	GC31MFC	/	



Refillable inkjet cartridge

Compatible inkjet cartridge



WEL-TRY-GC41BK	GC41BK	/	Ricoh Ipsio SG 3100 Ricoh Ipsio SG 2100 Ricoh Ipsio SG 2010L Ricoh Aficio SG 3110Dnw	
WEL-TRY-GC41C	GC41C	/		
WEL-TRY-GC41M	GC41M	/		
WEL-TRY-GC41Y	GC41Y	/		
WEL-TRY-GC42K	GC42K	/	Ricoh SG 5200 	
WEL-TRY-GC42C	GC42C	/		
WEL-TRY-GC42M	GC42M	/		
WEL-TRY-GC42Y	GC42Y	/		
WEL-TRY-GC42KH	GC42KH	/		
WEL-TRY-GC42CH	GC42CH	/		
WEL-TRY-GC42MH	GC42MH	/		
WEL-TRY-GC42YH	GC42YH	/		
WEL-TRY-GC51KH	GC51KH	/		
WEL-TRY-GC51CH	GC51CH	/		
WEL-TRY-GC51MH	GC51MH	/	Ricoh SG 3210DNw	
WEL-TRY-GC51YH	GC51YH	/		
AJSG-SG400&800BK	SG400&800 BK	/		SAWGRASS SG400/SG800 
AJSG-SG400&800C	SG400&800 C	/		
AJSG-SG400&800M	SG400&800 M	/		
AJSG-SG400&800Y	SG400&800 Y	/		
AJSG-SG500 BK	SG500 BK	/	SAWGRASS SG500/SG1000 	
AJSG-SG500 C	SG500 C	/		
AJSG-SG500M	SG500 M	/		
AJSG-SG500 Y	SG500 Y	/		





WEL-TRY for HP Series Inkjet Cartridge为彩惠普系列墨盒

OEM Ink Cartridge Type	OEM Product Code	Region	Color	Description
HP 10	C4840A	WW	K	HP Designjet Colorpro ga HP Designjet Colorpro cad HP Business Inkjet 2000c professional series HP Business Inkjet 2500c professional series HP Designjet 3000
	C4841A		C	
	C4842A		Y	
	C4843A		M	
	C4844A		K	HP Designjet 500/500PS/HP Designjet 800/800PS/HP Designjet 815mfp/820MFP/HP Designjet 1100/HP Designjet 2200/HP Designjet 2300/2230/2250/2280/2600/1700/HP Designjet100/110/HP Business inkjet 3000/3000n/3000dtn/HP Business Inkjet 2000c professional series/HP Business Inkjet 2500c professional series/HP Business Inkjet 1200/2800/HP Officejet Pro K850/HP Officejet 9110/9120/9130/HP Business Inkjet 1000
HP 11	C4836A	WW	C	HP Business Inkjet 1100 series HP Business Inkjet 2200/2300/2230 HP Business Inkjet 2250/2280/2600 series HP Color Inkjet Printer cp1700 HP Designjet 100/110/120/10PS/20PS/50PS HP Officejet Pro K850 HP Officejet 9110/9120/9130 HP Business Inkjet 1000 HP Business Inkjet 2800
	C4837A		M	
	C4838A		Y	HP Business Inkjet 1100 series HP Business Inkjet 2200/2300/2230 HP Business Inkjet 2250/2280/2600series HP Color Inkjet Printer cp1700 HP Designjet 100/110 plus Printer series HP Designjet 50ps HP Officejet Pro K850 HP Officejet 9110/9120/9130 HP Business Inkjet 1000 HP Business Inkjet 2800
HP 38	C9412A	WW	MK	HP Photosmart Pro B9180 HP Photosmart Pro B8850
	C9413A		PK	
	C9414A		LG	
	C9415A		C	
	C9416A		M	
	C9417A		Y	
	C9418A		LC	
	C9419A		LM	



HP10: C4844A-K;
HP11: C4836A-C,
 C4837A-M, C4838A-Y
 for HP 100,1000,1100,110,111,



Big volume without pump inkjet cartridge(110ml/color)



Big volume with pump inkjet cartridge(120ml/color)



Refillable/Compatible inkjet cartridge.



(with pump)



continuous ink supply system

for HP 100,1000,1100,110,111, 120,1200,120NR,2200,2230,2250, 2280,2300,2500C,C500CM,2600, 2600DN,2800,3800CP,70,9110, 9120,9130,CP1700,CP1700D, CP1700PS,K850. (BK,C,M,Y)

HP38 (28ml):

C9412A-MK, C9413A-PK, C9414A-LG, C9415A-C, C9416A-M, C9417A-Y, C9418A-LC, C9419A-LM. for HP Pro B9100,B9180,B8800, B8850(PK,LG,MK,C,M,Y,LM,LC)

HP 72	C9403A	WW	MK	HP Designjet T1110
	C9370A		K	HP Designjet T1120
	C9371A		C	HP Designjet T1300
	C9372A		M	HP Designjet T2300
	C9373A		Y	HP Designjet T610
	C9374A		Grey	HP Designjet T770
				HP Designjet T790
				HP Designjet T795



Big volume with pump inkjet cartridge

Big volume without pump inkjet cartridge

HP70: C9448A-MK,C9449A-PK,C9451A-LG, C9452A-C, C9453A-M,C9454A-Y,C9455A-LM,C9390A-LC
for hp Z2100,Z5200. (M,Y,LM,LC,PK,LG,MK,C)

HP70: C9448A-MK,C9449A-PK,C9451A-LG, C9453A-M,C9454A-Y,C9455A-LM,C9390A-LC, C9450A-G,
C9456A-R,C9457A-GN,C9458A-B,C9459A-L
for hp Z3100,Z3100PS,Z3200,Z3200PS (L,G,B,GN,M,Y+LM,LC,PK,LG,MK,R)

HP72: C9370A-PK,C9403A-MK, C9371A-C, C9372A-M, C9373A-Y, C9374A-G
for hp T610,T770,T1100,T1100PS,T1120,T1120PS,T2300.(G,PK,MK,Y,M,C)

HP 82	CH565A	WW	K	HP Designjet 510 series
	C4911A		C	HP Designjet 500/500PS HP Designjet 800/800PS HP Designjet 815mfp HP Designjet 820mfp HP Designjet 510 series
	C4912A		M	
	C4913A		Y	HP Designjet 500/500PS HP Designjet 800/800PS HP Designjet 815mfp HP Designjet 820mfp HP Designjet 10PS/20PS/50PS HP Designjet 510 series
HP 84	C5016A	WW	K	HP Designjet 90r/10ps/20ps/50ps/30/120/130 series
	C5017A		LC	HP Designjet 10ps/20ps/50ps/120 series
	C5018A		LM	
HP 85	C9425A	WW	C	HP Designjet 30/90r/130 series
	C9426A		M	
	C9427A		Y	
	C9428A		LC	
	C9429A		LM	
HP 88	C9385A	WW	K	HP Officejet PRO K550 K8600 HP Officejet PRO L7780 HP Officejet PRO L7580/L7590/L7680
	C9386A		C	
	C9387A		M	
	C9388A		Y	
	C9396A		K	
	C9391A		C	
	C9392A		M	
	C9393A		Y	



Big volume inkjet cartridge with pump
BK/Y/LC/LM: 320ml; C/M: 120ml



Big volume inkjet cartridge without pump
(BK/Y/LC/LM: 300ml; C/M: 110ml)




Refillable/Compatible inkjet cartridge.



continuous ink supply system

HP84(69ml):
C5016A-K;
HP85:
C9425A-C(28ml),
C9426A-M(28ml),
C9427A-Y(69ml),
C9428A-LC(69ml),
C9429A-LM(69ml)
for HP30,90,130.
(Y,BK, M,C,LM,LC)

HP 02	C8721W	USA/AP	K	HP Photosmart 3210/3310/ 8250/C5180/C6180/C7280/C8180 HP Photosmart D6160/D7160/D7260/D7360/D746 0 HP Photosmart D7300/D7100/D6100/C7100/C610 0/C5100/8200/3100 series HP Photosmart 3110/8230 HP Photosmart C5140/C5150/C6150/C6280/C718 0/C7250 HP Photosmart D6160/D7145/D7155/D7160/ D7260/D7345/D7355/D7360/D746 0
	C8719W		K	
	C8771W		C	
	C8772W		M	
	C8773W		Y	
	C8774W		LC	
	C8775W		LM	
	C8730WN		C	
	C8731WN		M	
C8732WN	Y			
HP 801	C8721Z	CHN/ IDN	K	HP Photosmart D7300/D7100/D6100/C7100/ C6100/C5100/8200/3100 series 
	C8719Z		K	
	C8771Z		C	
	C8772Z		M	
	C8773Z		Y	
	C8774Z		LC	
	C8775Z		LM	
HP 363	C8719E	EUR	K	HP Photosmart D7300/D7100/D6100/ C7100/C6100/C5100/8200/3100 series
	C8721E		K	
	C8771E		C	
	C8772E		M	
	C8773E		Y	
	C8774E		LC	
	C8775E		LM	
HP 177	C8721H	ME/AF/ JPN	K	HP Photosmart D7300/D7100/D6100/C7100/ C6100/C5100/8200/3100 series
	C8719H		K	
	C8771H		C	
	C8772H		M	

C8773H
C8774H
C8775H

Y
LC
LM

C6100/C5100/8200/3100 series



Refillable/Compatible inkjet cartridge

8721BK, 8771C, 8772M, 8773Y, 8774LC, 8775LM

02 for use on: Photomart 3110,3210,3210V,3213,3310,8230,8238,8250,C5140,C5150,C5180,C5185,C6150,C6180,C6280,C7150,C7180,C7280,C8180,D7145,D7155,D7160,D7345,D7355,D7360,D7260,D7460.

801 for use on: hp 3108,3308,8238; D7168,D7268,D7368; C5188,C6188,C7188,C7288, C6288, C8188.

177 for use on: hp 3213,3313,8200,3210.

363 for use on: hp 3213,3313,8200.

HP 564	CB316W	USA/SA/LA/A NZ/AP	K	HP Photosmart B8550 HP Photosmart B8500 HP Photosmart C6324/C6340/C6350/C6375/C6380/C6383/C6388 HP Photosmart D5460/D5463/D5468/D7560 HP Photosmart 7510 e-AIO-C331a HP Photosmart 7515 - C311a HP Photosmart 7525 e-All-in-One HP Photosmart Plus AIO B209a HP Photosmart Plus AIO B210a/b/c/d/e HP Photosmart Premium Fax AIO C309a/g/n HP Photosmart Premium touchsmart WEB AIO C309n HP Photosmart Premium e-ALL-in-One C310a/b/c HP Photosmart eStation C510a HP Photosmart Premium Fax C410 HP Photosmart D5445 HP Photosmart D5400 HP Photosmart 7520 HP Photosmart 5510 e-AIO B111a HP Photosmart 5520 HP Photosmart 5514 e-AIO B111h HP Photosmart 6510 e-AIO B211a HP Photosmart 6512 e-AIO B211a HP Photosmart 6515 e-AIO B211a HP Officejet 4610 All-in-One Printer HP Officejet 4622 e-All-in-One Printer HP Officejet 4620 e-All-in-One Printer HP Deskjet 3070A AIO HP Deskjet 3520
	CB317W		PK	
	CB318W		C	
	CB319W		M	
	CB320W		Y	
	CN684W		K	
	CB322W		PK	
	CB323W		C	
	CB324W		M	
	CB325W		Y	
HP 364	CB316E	EUR	K	HP Photosmart Premium e-All-in-One Printer HP Photosmart 7510 e-AIO-C311a HP Photosmart Plus AIO HP Photosmart Pro B8550/B8553 HP Photosmart C5324/C5370/C5373/C5380/C5383/C5388 HP Photosmart C5390/C5393/C6300/C6324/C6380 HP Photosmart D5460/D5463/D5468 HP Photosmart B109a/b/c/d AIO HP Photosmart B109f Special Edition AIO HP Photosmart B109n/g/a/c/d/e Wireless AIO HP Photosmart Plus B210a/b/c/e AIO HP Photosmart Premium C309a/c/g/h/n AIO HP Photosmart Premium C310A-AIO HP Photosmart Premium C310 e-AIO HP Photosmart Premium FAX C309AIO HP Photosmart Premium Fax C309a HP Photosmart Premium FAX e-AIO C410h HP Photosmart eStation C510a HP Photosmart C410h
	CB317E		PK	
	CB318E		C	
	CB319E		M	
	CB320E		Y	
	CN684E		K	
	CB322E		PK	

	CB323E		C	HP Photosmart 5510 e-AIO B111a/h/c HP Photosmart 5515 e-All-in-One Printer HP Photosmart 6510 e-AIO B211b HP Officejet 4620 e-All-in-One Printer HP Deskjet 3070A AIO HP Photosmart plus B209a HP Photosmart B110a HP Photosmart B109n
	CB324E		M	
	CB325E		Y	
HP 178	CB316H	JPN/ ME	K	HP Photosmart AIO HP Photosmart 7510 e-AIO-C311a
	CB317H		PK	HP Photosmart Plus AIO/HP Photosmart Pro B8550/B8553/HP Photosmart
	CB318H		C	C5324/C5370/C5373/C5380/C5383/C5388/HP Photosmart
	CB319H		M	C5390/C5393/C6300/C6324/C6380 HP Photosmart
	CB320H		Y	D5460/D5463/D5468/HP Photosmart B109a/c/d AIO/HP Photosmart B109f Special Edition
	CN684H		K	AIO/HP Photosmart B109n/q/a/c/d/e Wireless AIO/HP
	CB322H		PK	Photosmart Plus B209a/b/c/HP Photosmart Plus B210a/b/c/e
	CB323H		C	AIO/HP Photosmart Premium C309/a/c/g/h/n AIO/HP
	CB324H		M	Photosmart Premium C309A-AIO/HP Photosmart Premium C309 e-AIO/HP Photosmart Premium FAX C309 AIO/HP
	CB325H		Y	Photosmart Premium Fax C309a/HP Photosmart Premium FAX e-AIO C410b/HP Photosmart Premium C410c/HP Photosmart 5510 e-AIO B111a/h/c/HP
			CB316Z	CN
CB317Z	PK	HP Photosmart C5324/C5370/C5373/C5380/C5383/C5388		
CB318Z	C	HP Photosmart C5390/C5393/C6324/C6388		
CB319Z	M	HP Photosmart D5460/D5468/D7560		
CB320Z	Y	HP Photosmart 7510 e-AIO-C311a		
CN684Z	K	HP Photosmart Plus AIO B209a HP Photosmart Plus e-AIO B210a		
CB322Z	PK	HP Photosmart Premium AIO C309g		
CB323Z	C	HP Photosmart Premium e-AIO C310a		
CB324Z	M	HP Photosmart Premium Fax AIO C309a		
CB325Z	Y	HP Photosmart Premium Fax e-AIO C410d HP Photosmart Wireless e-AIO B110 HP Photosmart 5510 e-AIO B111a/g		
HP 920	CD971A	WW	K	HP OfficeJet 6000 HP OfficeJet 6000 AIO-E608a HP Officejet 6000 Printer - E609a
	CH634A		C	HP OfficeJet 6000 W AIO-E609n HP OfficeJet 6000 W
	CH635A		M	HP OfficeJet 6500 AIO HP OfficeJet 6500 W AIO
	CH636A		Y	HP OfficeJet 6500 W AIO-E609a HP OfficeJet 6500 AIO(US)E709 HP OfficeJet 6500 AIO-E709a/n HP OfficeJet 6500 W AIO-E709n
	CD975A		K	HP OfficeJet 6500A e-AIO E710a HP OfficeJet 6500A AIO-E710a HP OfficeJet 6500A Plus e-AIO

	CD972A		C	E710n HP OfficeJet 6500A C-AIO HP OfficeJet 7000 WF HP OfficeJet 7000 WF-E809a HP OfficeJet 7500A WF HP OfficeJet 7500A e-AIO E910 HP OfficeJet 7500A WF e-AIO E910a
	CD973A		M	
	CD974A		Y	
HP 685	CZ121AA	ANZ/ AP/ CHN	K	HP Deskjet Ink Advantage 3525 HP Deskjet Ink Advantage 4615 HP Deskjet Ink Advantage 4625 HP Deskjet Ink Advantage 5525 HP Deskjet Ink Advantage 6525
	CZ122AA		C	
	CZ123AA		M	
	CZ124AA		Y	
HP 655	CZ109AE	MEA/ RUS	K	HP Deskjet Ink Advantage 3525 HP Deskjet Ink Advantage 4615 HP Deskjet Ink Advantage 4625 HP Deskjet Ink Advantage 5525 HP Deskjet Ink Advantage 6525
	CZ110AE		C	
	CZ111AE		M	
	CZ112AE		Y	
HP 934	C2P19A	WW	K	HP Officejet Pro 6230 ePrinter HP Officejet Pro 6830 e-All-in-One HP Officejet 6815 e-AiO Printer HP Officejet 6812 e-AiO Printer HP OfficeJet Pro 6835 e-AiO printer HP OfficeJet 6820 e-tout-en-un
	C2P20A		C	
	C2P21A		M	
	C2P22A		Y	
	C2P23A		K	
	C2P24A		C	
	C2P25A		M	
	C2P26A		Y	
HP 902	T6M18AN	NA	K	HP OfficeJet 6960 All-in-One Printer
	T6M14AN		K	HP OfficeJet 6954 All-in-One Printer
	T6M02AN		C	HP OfficeJet 6960 All-in-One Printer
	T6M06AN		M	HP OfficeJet 6962 All-in-One Printer
	T6M10AN		Y	HP OfficeJet Pro 6960 All-in-One Printer
	T6L98AN		K	HP OfficeJet Pro 6968 All-in-One Printer
HP 903	T6M19AE	EUR	K	HP OfficeJet Pro 6975 All-in-One Printer HP OfficeJet 6960 All-in-One Printer
	T6M15AE		K	HP OfficeJet 6950 All-in-One Printer
	T6M03AE		C	HP OfficeJet 6960 All-in-One Printer
	T6M07AE		M	HP OfficeJet Pro 6960 All-in-One Printer
	T6M11AE		Y	HP OfficeJet Pro 6970 All-in-One Printer
	T6L99AE		K	
HP 905	T6M21AA	AP	K	HP OfficeJet 6960 All-in-One Printer
	T6M17AA		K	
	T6M05AA		C	HP OfficeJet 6960 All-in-One Printer
	T6M09AA		M	HP OfficeJet Pro 6960 All-in-One Printer
	T6M13AA		Y	HP OfficeJet Pro 6970 All-in-One Printer
	T6M01AA		K	
	T6M20AL		K	
	T6M16AL		K	

HP 904	T6M04AL	SA	C	HP OfficeJet Pro 6970 All-in-One Printer	
	T6M08AL		M		
	T6M12AL		Y		
	T6M00AL		K		
HP 910	3YL66AN	NA	K	HP OfficeJet Pro 8035 All-in-One Printer	
	3YL65AN		K	HP OfficeJet 8010 All-in-One Printer HP OfficeJet 8015 All-in-One Printer HP OfficeJet 8018 All-in-One Printer HP OfficeJet 8022 All-in-One Printer HP OfficeJet Pro 8020 All-in-One Printer HP OfficeJet Pro 8025 All-in-One Printer HP OfficeJet Pro 8028 All-in-One Printer HP OfficeJet Pro 8035 All-in-One Printer	
	3YL62AN		C		
	3YL63AN		M		
	3YL64AN		Y		
	3YL61AN		K		
	3YL58AN		C		
	3YL59AN		M		
	3YL60AN		Y		
	HP 912		3YL85AE		EUR
3YL84AE		K			
3YL81AE		C			
3YL82AE		M			
3YL83AE		Y			
3YL80AE		K			
3YL77AE		C			
3YL78AE		M			
3YL79AE		Y			
HP 915		3YM23AA	AP	K	
	3YM22AA	K		HP OfficeJet 8020 All-in-One Printer	
	3YM19AA	C		HP OfficeJet Pro 8020 All-in-One Printer	
	3YM20AA	M		HP OfficeJet Pro 8022 All-in-One Printer	
	3YM21AA	Y		HP OfficeJet Pro 8023 All-in-One Printer	
	3YM18AA	K		HP OfficeJet Pro 8024 All-in-One Printer	
	3YM15AA	K		HP OfficeJet Pro 8025 All-in-One Printer	
		C		HP OfficeJet Pro 8026 All-in-One Printer	

3YM16AA
3YM17AA

M
Y

HP OfficeJet Pro 8028 All-in-One Printer
 HP OfficeJet Pro 8035 All-in-One Printer



HP564,HP564XL for HP: B8500,B8550,B8558,C309,C5300,C5324,C5370,C5373,C5380,C5383,C5390,C6324,C6340,C6350,C6375,C6380,C6383,C6388,D5460,D5463,D5468,D7560,D5445. **(BK,M,C,Y,BK-XL)**

HP920,HP920XL for HP: 6000,6500,6500W,7000. **(M,C,Y,BK-XL)**

HP364,HP364XL for HP: B109,B110,B209,B8550,B8553,B8558,C309,C5300,C5380,C6300,C6380,D5400,D5460,D5463,D5468,D7560. **(BK,M,C,Y,BK-XL)**

HP862,HP862XL for HP: D5468,B8558,C5388,C309, B209,B210. **(BK,M,C,Y,BK-XL)**

HP178,HP178XL for HP: C5383,C6283,C6383,D5463,B8353,CC335C,CN216C,CN245C,CN255C,CN503C,CQ521C. **(BK,M,C,Y,BK-XL)**

HP 940	C4902AA	WW	K	HP Officejet Pro 8000 -A809a HP Officejet Pro 8000 Enterprise Printer - A811a HP Officejet Pro 8000 Printer- A809a HP Officejet Pro 8000 Wireless Printer - A809n HP Officejet Pro 8500 - A909b HP Officejet Pro 8500 AIO Printer - A909a HP Officejet Pro 8500 Premier AIO Printer - A909n HP Officejet Pro 8500 Wireless AIO Printer - A909g HP Officejet Pro 8500A -A910a HP Officejet Pro 8500A e-AIO Printer - A910a HP Officejet Pro 8500A Plus e-AIO Printer - A910g HP Officejet Pro 8500A Premium-e-AIO Printer -A910n
	C4901A		C	
	C4902A		M	
	C4903A		Y	
	C4906A		K	
	C4907A		C	
	C4908A		M	
	C4909A		Y	



HP88,HP88XL:
 C9386A-C, C9387A-M,
 C9388A-Y, C9385A-K,
 C9391A-C, C9392A-M,
 C9393A-Y, C9396A-K.
 for use on HP PRO K550,K8600,
 K8600DN,K5400,K5400N,K5400DN,
 K5400DTN,L7400,L7480,L7500,
 L7580,L7590,L7600,L7680,
 L7700,L7780. **(C,M,Y,K)**

HP940,HP940XL
(with pump inkjet cartridge)
 C4903A-C.C4904A-M.



C4903A-C, C4904A-M,
C4905A-Y, C4902A-K,
C4907A-C-XL, C4908A-M-XL,
C4909A-Y-XL, C4906A-K-XL.
for use on HP PRO 8000, 8500.
(C, M, Y, K)

HP 950	CN045A	WW	K	HP Officejet Pro 8100 ePrinter HP Officejet Pro 8600 e-AIO Printer HP Officejet Pro 8600 Plus e-AIO Printer HP Officejet Pro 8600 Premium e-AIO Printer-N911 HP Officejet Pro 8610/8620/8630/8640/8660/8615/8625 HP Officejet Pro 251DW/276DW
	CN046A		C	
	CN047A		M	
	CN048A		Y	
	CN049A		K	
	CN050A		C	
	CN051A		M	
	CN052A		Y	
HP 932	CN053A	WW	K	HP Officejet 6100 ePrinter - H611a HP Officejet 6600 e-AIO Printer - H711a HP Officejet 6700 Premium e-AIO Printer - H711n HP Officejet Officejet 7110 wide Format ePrinter HP Officejet 7612 HP Officejet 7610 HP Officejet 7510
	CN054A		C	
	CN055A		M	
	CN056A		Y	
	CN057A		K	
	CN058A		C	
	CN059A		M	
	CN060A		Y	
HP 960	CZ665AA	WW	K	HP Officejet Pro 3610 HP Officejet Pro 3620
	CZ666AA		K	
HP 711	CZ133A	WW	K	HP Designjet T120 HP Designjet T520
	CZ130A		C	
	CZ131A		M	
	CZ132A		Y	
HP 952	LOR39AN	NA	K	HP OfficeJet Pro 7720 Wide Format All-in-One Printer HP OfficeJet Pro 8216 All-in-One Printer HP OfficeJet Pro 8720 All-in-One Printer HP OfficeJet Pro 8725 All-in-One Printer HP OfficeJet Pro 8730 All-in-One Printer HP OfficeJet Pro 8740 All-in-One Printer
	F6U19AN		K	
	LOS61AN		C	

	L0S64AN		M	Printer HP OfficeJet Pro 8715 All-in-One Printer HP OfficeJet Pro 8720 All-in-One Printer HP OfficeJet Pro 8725 All-in-One Printer
	L0S67AN		Y	HP OfficeJet Pro 8730 All-in-One Printer HP OfficeJet Pro 8740 All-in-One Printer
HP 953	L0R40AE	EUR	K	HP OfficeJet Pro 7720 Wide Format All-in-One Printer
	L0S70AE		K	HP OfficeJet Pro 7720 Wide Format All-in-One Printer
	F6U16AE		C	HP OfficeJet Pro 7730 Wide Format All-in-One Printer
	F6U17AE		M	HP OfficeJet Pro 7740 Wide Format All-in-One Printer
	F6U18AE		Y	HP OfficeJet Pro 8210 All-in-One Printer HP OfficeJet Pro 8218 All-in-One
HP 955	L0R42AA	AP	K	HP OfficeJet Pro 7720 Wide Format All-in-One Printer
	L0S72AA		K	HP OfficeJet Pro 7720 Wide Format All-in-One Printer
	L0S63AA		C	HP OfficeJet Pro 7730 Wide Format All-in-One Printer
	L0S66AA		M	HP OfficeJet Pro 7740 Wide Format All-in-One Printer
	L0S69AA		Y	HP OfficeJet Pro 8210 All-in-One Printer HP OfficeJet Pro 8216 All-in-One
HP 954	L0R41AL	SA	K	HP OfficeJet Pro 7720 de gran formato
	L0S71AL		K	HP OfficeJet Pro 7720 de gran formato
	L0S62AL		C	HP OfficeJet 7740 Todo-en-Uno de formato ancho
	L0S65AL		M	HP OfficeJet Pro 8210 HP OfficeJet Pro 8710
	L0S68AL		Y	HP OfficeJet Pro 8720 HP OfficeJet Pro 8730
HP 962	3JA04AN	NA	K	HP OfficeJet Pro 9020 All-in-One Printer
	3JA03AN		K	HP OfficeJet Pro 9010 All-in-One Printer
	3JA00AN		C	HP OfficeJet Pro 9012 All-in-One Printer
	3JA01AN		M	HP OfficeJet Pro 9015 All-in-One Printer
	3JA02AN		Y	HP OfficeJet Pro 9016 All-in-One Printer
	3HZ99AN		K	HP OfficeJet Pro 9018 All-in-One Printer
	3HZ96AN		C	HP OfficeJet Pro 9019 All-in-One Printer
	3HZ97AN		M	HP OfficeJet Pro 9020 All-in-One Printer
	3HZ98AN		Y	HP OfficeJet Pro 9025 All-in-One Printer
	3JA31AE		K	HP OfficeJet Pro 9020 All-in-One Printer HP OfficeJet Pro 9022 All-in-One
	3JA30AE		K	HP OfficeJet Pro 9010 All-in-One Printer
	3JA27AE		C	HP OfficeJet Pro 9012 All-in-One Printer
	3JA28AE		M	HP OfficeJet Pro 9014 All-in-One Printer

HP 963	3JA29AE	EUR	Y	HP OfficeJet Pro 9015 All-in-One Printer
	3JA26AE		K	HP OfficeJet Pro 9016 All-in-One Printer
	3JA23AE		C	HP OfficeJet Pro 9019 All-in-One Printer
	3JA24AE		M	HP OfficeJet Pro 9020 All-in-One Printer
	3JA25AE		Y	HP OfficeJet Pro 9022 All-in-One Printer HP OfficeJet Pro 9025 All-in-One Printer
HP 964	3JA57AL	SA	K	HP OfficeJet Pro 9010 All-in-One Printer HP OfficeJet Pro 9016 All-in-One Printer HP OfficeJet Pro 9018 All-in-One Printer HP OfficeJet Pro 9020 All-in-One Printer
	3JA54AL		C	
	3JA55AL		M	
	3JA56AL		Y	
	3JA53AL		K	
	3JA50AL		C	
	3JA51AL		M	
3JA52AL	Y			
HP 965	3JA85AA	AP	K	HP OfficeJet Pro 9020 All-in-One Printer
	3JA84AA		K	HP OfficeJet Pro 9010 All-in-One Printer HP OfficeJet Pro 9012 All-in-One Printer HP OfficeJet Pro 9016 All-in-One Printer HP OfficeJet Pro 9018 All-in-One Printer HP OfficeJet Pro 9019 All-in-One Printer HP OfficeJet Pro 9020 All-in-One Printer HP OfficeJet Pro 9026 All-in-One Printer HP OfficeJet Pro 9028 All-in-One Printer
	3JA81AA		C	
	3JA82AA		M	
	3JA83AA		Y	
	3JA80AA		K	
	3JA77AA		C	
	3JA78AA		M	
	3JA79AA		Y	





HP 970	CN621A	WW	K	HP Officejet Pro X451dn HP Officejet Pro X551dw HP Officejet Pro X476dn HP Officejet Pro X576dw
	CN622A		C	
	CN623A		M	
	CN624A		Y	
	CN625A		K	
	CN626A		C	
	CN627A		M	
	CN628A		Y	
HP 980	D8J10A	WW	K	HP Officejet Enterprise X555xh/dn HP Officejet Enterprise Color Flow X585z/dn/f
	D8J07A		C	
	D8J08A		M	
	D8J09A		Y	
...	F6T84AN	...	K	HP pagewide pro 452dn/dw HP PageWide Pro MFP 477dn/dw HP PageWide Pro 552dn/dw HP PageWide Pro MFP 577dw/z HP PageWide Managed P55250dw HP PageWide Managed MFP P57750dw
	L0R98AN		C	
	L0S01AN		M	
	L0S04AN		Y	

HP 972	F6T80AN	NA	K	HP Pagewide 352dw HP Pagewide MFP 377dw HP Pagewide pro 452dn/dw HP PageWide Pro MFP 477dn/dw HP PageWide Pro 552dw HP PageWide Pro MFP 577dw/z HP PageWide Managed P55250dw HP PageWide Managed P57750dw
	L0R86AN		C	
	L0R89AN		M	
	L0R92AN		Y	
HP 973	L0S07AE	EUR	K	HP Pagewide pro 452dn/dw HP PageWide Pro MFP 477dn/dw HP PageWide Pro 552dw HP PageWide Pro MFP 577dw/z HP PageWide Managed P55250dw HP PageWide Managed MFP P57750dw
	F6T81AE		C	
	F6T82AE		M	
	F6T83AE		Y	
	L0R95AE		K	HP Pagewide 352dw HP Pagewide MFP 377dw HP Pagewide pro 452dn/dw HP PageWide Pro MFP 477dn/dw HP PageWide Pro 552dw HP PageWide Pro MFP 577dw/z HP PageWide Managed P55250dw HP PageWide Managed MFP P57750dw
	F6T77AE		C	
	F6T78AE		M	
	F6T79AE		Y	
HP 975	L0S09AA	AP	K	HP PageWide Pro 452dn/dw HP PageWide Pro MFP 477dw/dn HP PageWide Pro 552dw HP PageWide Pro MFP 577dw/z HP PageWide Managed P55250dw HP PageWide Managed MFP P57750dw
	L0S00AA		C	
	L0S03AA		M	
	L0S06AA		Y	
	L0R97AA		K	HP Pagewide 352dw HP Pagewide MFP 377dw/dn HP PageWide Pro 452dw/dn HP PageWide Pro 552dw HP PageWide Pro MFP 577dw/Z HP PageWide Managed P55250dw HP PageWide Managed MFP P57750dw
	L0R88AA		C	
	L0R91AA		M	
	L0R94AA		Y	
HP 974	L0S08AL	SA	K	HP PageWide Pro 452dw HP PageWide Pro MFP 477dw HP PageWide Pro 552dw HP PageWide Pro MFP 577dw HP PageWide Managed P55250dw HP PageWide Managed MFP P57750dw
	L0R99AL		C	
	L0S02AL		M	
	L0S05AL		Y	
	L0R96AL		K	HP Pagewide 352dw HP Pagewide MFP 377dw HP PageWide Pro 452dw HP PageWide Pro MFP 477dw HP PageWide Pro 552dw HP PageWide Pro MFP 577dw HP PageWide Managed P55250dw HP PageWide Managed MFP P57750dw
	L0R87AL		C	
	L0R90AL		M	
	L0R93AL		Y	
HP 976Y	L0R08A	WW	K	HP PageWide Pro 552dw/dn HP PageWide Pro MFP 577dw/z HP PageWide Managed P55250dw HP PageWide Managed MFP
	L0R05A		C	
	L0R06A		M	

	L0R07A		Y	P57750dw
HP 981	L0R16A	WW	K	HP PageWide Enterprise Color 556xh/dn HP PageWide Enterprise Color MFP 586dn/f/z HP PageWide Managed Color MFP E58650dn (NA) HP PageWide Managed Color MFP E55650 (AP)
	L0R13A		C	
	L0R14A		M	
	L0R15A		Y	
	L0R12A		K	
	L0R09A		C	
	L0R10A		M	
	L0R11A		Y	
	J3M71A		K	
	J3M68A		C	
	J3M69A		M	
	J3M70A		Y	
	HP 990		M0K01AN	
M0J89AN		C		
M0J93AN		M		
M0J97AN		Y		
HP 991	M0K02AE	EUR	K	
	M0J90AE		C	
	M0J94AE		M	
	M0J98AE		Y	
HP 992	M0K03AL	SA	K	
	M0J91AL		C	
	M0J95AL		M	
	M0J99AL		Y	
HP 993	M0K04AA	AP	K	
	M0J92AA		C	
	M0J96AA		M	
	M0K00AA		Y	
HP 982	T0B30A	WW	K	HP PageWide Enterprise Color 765dn HP PageWide Enterprise Color MFP 780dn HP PageWide Enterprise Color Flow MFP 785f/zs HP PageWide Enterprise Color
	T0B27A		C	
	T0B28A		M	
	T0B29A		Y	
HP 993	W1B44A	WW	/	HP PageWide Pro MFP 777z HP PageWide Pro MFP 772dn HP PageWide Pro 750dw HP PageWide Color MFP 774dn/dns HP PageWide Color MFP 779dn/dns HP PageWide Color 755dn HP PageWide Enterprise Color 765dn HP PageWide Enterprise Color MFP 780dn HP PageWide Enterprise Color Flow MFP 785f/zs/z+





Refillable inkjet cartridge

CISS



为彩兄弟系列产品兄弟一代WEL-TRY for Brother I Series Cartridge

Product Code	OEM Product	Region	Color	Description
WEL-TRY-LC110BK	LC110BK		K	Brother DCP-J152N Brother DCP-J132N Brother DCP-J137N
WEL-TRY-LC110C	LC110C		C	
WEL-TRY-LC110M	LC110M		M	
WEL-TRY-LC110Y	LC110Y		Y	
WEL-TRY-LC111BK	LC111BK		K	Brother MFC-J980DN/DWN Brother MFC-J870N/J890DN/DWN Brother MFC-J820DN/J827DWN /J720/727D/DW Brother DCP- J952N/J752N/J552NW/J957N- B/W Brother MFC-J877N/J987DN/DW Brother MFC-
WEL-TRY-LC111C	LC111C		C	
WEL-TRY-LC111M	LC111M		M	

WEL-TRY-LC111Y	LC111Y
WEL-TRY-LC113BK	LC113BK
WEL-TRY-LC113C	LC113C
WEL-TRY-LC113M	LC113M
WEL-TRY-LC113Y	LC113Y
WEL-TRY-LC115C	LC115C
WEL-TRY-LC115M	LC115M
WEL-TRY-LC115Y	LC115Y
WEL-TRY-LC117BK	LC117BK
WEL-TRY-LC119BK	LC119BK
WEL-TRY-LC121BK	LC121BK
WEL-TRY-LC121C	LC121C
WEL-TRY-LC121M	LC121M
WEL-TRY-LC121Y	LC121Y
WEL-TRY-LC123BK	LC123BK
WEL-TRY-LC123C	LC123C
WEL-TRY-LC123M	LC123M
WEL-TRY-LC123Y	LC123Y
WEL-TRY-LC125C	LC125C
WEL-TRY-LC125M	LC125M
WEL-TRY-LC125Y	LC125Y
WEL-TRY-LC127BK	LC127BK
WEL-TRY-LC129BK	LC129BK
WEL-TRY-LC101BK	LC101BK
WEL-TRY-LC101C	LC101C
WEL-TRY-LC101M	LC101M
WEL-TRY-LC101Y	LC101Y
WEL-TRY-LC103BK	LC103BK
WEL-TRY-LC103C	LC103C
WEL-TRY-LC103M	LC103M
WEL-TRY-LC103Y	LC103Y
WEL-TRY-LC105C	LC105C
WEL-TRY-LC105M	LC105M
WEL-TRY-LC105Y	LC105Y

JPN

EUR

USA

Y	Brother MFC- J897DNDWN/J827DN/DWN /J727D/DW
K	
C	Brother MFC- J4910CDW/J4810DN /J4510N Brother DCP-J4215N/J4210N
M	Brother MFC- J6975CDW/J6970CDW
Y	Brother MFC- J6770CDW/J6570CDW
C	Brother MFC- J6770CDW/J6570CDW
M	Brother MFC-J6573CDW
Y	Brother MFC-J6973CD
K	Brother MFC- J4910CDW/J4810DN/J4510N Brother DCP-J4215N/J4210N
K	Brother MFC- J6975CDW/J6970CDW Brother MFC- J6770CDW/J6570CDW Brother MFC-J6573CDW Brother MFC-J6973CD
K	Brother DCP- J132W/J152W/J552W Brother DCP-J172W/J752W
C	Brother MFC- J870DW/J650DW/J470DW
M	
Y	Brother DCP- J132W/J152W/J552W Brother DCP-J172W/J752W Brother MFC- J870DW/J650DW/J470DW Brother DCP-J4110DW
K	Brother MFC- J4410DW/J4510DW/J4610DW/J4 710DW
C	Brother MFC- J6920DW/J6720DW/J6520DW
M	Brother MFC- J4410DW/J4510DW/J4610DW/J4 710DW
Y	Brother MFC- J6920DW/J6720DW/J6520DW
K	Brother MFC- J4410DW/J4510DW/J4610DW/J4 710DW
K	Brother MFC- J6920DW/J6720DW/J6520DW
K	Brother DCP-J152W Brother MFC- J245/J285DW/J450DW/J470DW/J 475DW
C	Brother MFC- J650DW/J870DW/J875DW
M	Brother DCP-J152W Brother MFC- J245/J285DW/J450DW/J470DW/J 475DW
Y	Brother MFC- J650DW/J870DW/J875DW
C	Brother MFC- J4310DW/J4410DW/J4510DW/J4 610DW/J4710DW
M	Brother MFC- J6520DW/J6720DW/J6920DW
Y	

WEL-TRY-LC107BK	LC107BK		K	Brother MFC-J4310DW/J4410DW/J4510DW/J4610DW/J4710DW	
WEL-TRY-LC109BK	LC109BK		K	Brother MFC-J6520DW/J6720DW/J6920DW	
WEL-TRY-LC563BK	LC-563BK	AP	K	Brother MFC-J3720 Brother MFC-J2510 Brother MFC-J2310 Brother MFC-J3520	
WEL-TRY-LC563C	LC-563C		C		
WEL-TRY-LC563M	LC-563M		M		
WEL-TRY-LC563Y	LC-563Y		Y		
WEL-TRY-LC565XLC	LC-565XL-C		C		
WEL-TRY-LC565XLM	LC-565XL-M		M		
WEL-TRY-LC565XLY	LC-565XL-Y		Y		
WEL-TRY-LC567XLBK	LC-567XL-BK		K		Brother MFC-J2510/MFC-J2310
WEL-TRY-LC569BK	LC569BK		K		Brother MFC-J3720/MFC-J3520
WEL-TRY-LC131BK	LC131BK		AUS		K
WEL-TRY-LC131C	LC131C	C			
WEL-TRY-LC131M	LC131M	M			
WEL-TRY-LC131Y	LC131Y	Y			
WEL-TRY-LC133BK	LC133BK	K		Brother DCP-J152W/J552W/J752W/J172W Brother MFC-J870DW/J650DW/J470DW Brother DCP-J4110DW Brother MFC-J4410N/J4510N/J4710DW Brother MFC-J6520DW/J6720DW/J6920DW	
WEL-TRY-LC133C	LC133C	C			
WEL-TRY-LC133M	LC133M	M			
WEL-TRY-LC133Y	LC133Y	Y			
WEL-TRY-LC135C	LC135C	C			
WEL-TRY-LC135M	LC135M	M			
WEL-TRY-LC135Y	LC135Y	Y			
WEL-TRY-LC137BK	LC137BK	K	Brother MFC-J4410N/J4510N/J4710DW		
WEL-TRY-LC139BK	LC139BK	K	Brother MFC-J6520DW/J6720DW/J6920DW		
WEL-TRY-LC161BK	LC161BK	HK	K		Brother DCP-J152W Brother DCP-J752DW Brother MFC-J245 Brother MFC-J470DW Brother MFC-650DW Brother MFC-J870DW
WEL-TRY-LC161C	LC161C		C		
WEL-TRY-LC161M	LC161M		M		
WEL-TRY-LC161Y	LC161Y		Y		
WEL-TRY-LC163BK	LC163BK		K		
WEL-TRY-LC163C	LC163C		C		
WEL-TRY-LC163M	LC163M		M		
WEL-TRY-LC163Y	LC163Y		Y		
WEL-TRY-LC583BK	LC583BK	IND	K	Brother MFC-J3720 Brother MFC-J3520	
WEL-TRY-LC583C	LC583C		C		
WEL-TRY-LC583M	LC583M		M		
WEL-TRY-LC583Y	LC583Y		Y		
WEL-TRY-LC589XLBK	LC589XLBK		K		
WEL-TRY-LC585XLC	LC585XLC		C		
WEL-TRY-LC585XLM	LC585XLM		M		
WEL-TRY-LC585XLY	LC585XLY		Y		
WEL-TRY-LC10EBK	LC10EBK	USA	K	Brother MFC-J6925DW	
WEL-TRY-LC10EC	LC10EC		C		
WEL-TRY-LC10EM	LC10EM		M		
WEL-TRY-LC10EY	LC10EY		Y		
WEL-TRY-LC12EBK	LC12EBK		K		

WEL-TRY-LC12EC	LC12EC	EUR	C	Brother MFC-J6925DW
WEL-TRY-LC12EM	LC12EM		M	
WEL-TRY-LC12EY	LC12EY		Y	
WEL-TRY-LC15EBK	LC15EBK	JPN	K	Brother MFC-J6990CDW
WEL-TRY-LC15EC	LC15EC		C	
WEL-TRY-LC15EM	LC15EM		M	
WEL-TRY-LC15EY	LC15EY		Y	



WEL-TRY For Brother II Series Cartridge为彩兄弟2代产品

Product Code	OEM Product Code	Region	Color	Description
WEL-TRY-LC209XXLBK	LC209XXLBK	USA	K	Brother MFC-J5520DW/J5620DW/J5720DW
WEL-TRY-LC207XXLBK	LC207XXLBK		K	Brother MFC-J4320DW/J4420DW/J4620DW
WEL-TRY-LC205XXLC	LC205XXLC		C	Brother MFCJ4320DW/J4420DW/J4620DW
WEL-TRY-LC205XXLM	LC205XXLM		M	
WEL-TRY-LC205XXLY	LC205XXLY		Y	
WEL-TRY-LC203BK	LC203BK		K	
WEL-TRY-LC203C	LC203C		C	Brother MFCJ5520DW/J5620DW/J5720DW
WEL-TRY-LC203M	LC203M		M	
WEL-TRY-LC203Y	LC203Y		Y	Brother MFC-J460DW/MFC-J480DW/MFC-J485DW/MFC-J680DW/
WEL-TRY-LC201BK	LC201BK		K	MFC-J880DW/MFC-J885DW

WEL-TRY-LC201C	LC201C		C	(Above printers can only use LC203/LC201)	
WEL-TRY-LC201M	LC201M		M		
WEL-TRY-LC201Y	LC201Y		Y		
WEL-TRY-LC229XLBK	LC229XLBK	EUR	K	Brother MFC-J5320DW/J5620DW/J5625DW/J5720DW	
WEL-TRY-LC227XLBK	LC227XLBK		K	Brother DCP-4120DW Brother MFC-J4420DW/J4620DW/J4625DW	
WEL-TRY-LC225XLC	LC225XLC		C	Brother DCP-4120DW Brother MFC-J4420DW/ J4620DW/ J4625DW Brother MFC-J5320DW/ J5620DW/ J5625DW/J5720DW Brother DCP-J562DW/MFC- J480DW/MFC-J680DW/MFC- J880DW (Above printers can only use LC223/LC221)	
WEL-TRY-LC225XLM	LC225XLM		M		
WEL-TRY-LC225XLY	LC225XLY		Y		
WEL-TRY-LC223BK	LC223BK		K		
WEL-TRY-LC223C	LC223C		C		
WEL-TRY-LC223M	LC223M		M		
WEL-TRY-LC223Y	LC223Y		Y		
WEL-TRY-LC221BK	LC221BK		K		
WEL-TRY-LC221C	LC221C		C		
WEL-TRY-LC221M	LC221M		M		
WEL-TRY-LC221Y	LC221Y		Y		
WEL-TRY-LC219XLBK	LC219XLBK		JPN	K	Brother MFC-J5620CDW/J5720CDW/J5820DW
WEL-TRY-LC217XLBK	LC217XLBK			K	Brother DCP-J4220N-B/W Brother MFC-J4720N
WEL-TRY-LC215XLC	LC215XLC			C	Brother DCP-J4220N-B/W 4225N-W/B Brother MFC-J4720N/J4725N Brother MFC-J5620CDW/ J5720CDW/J5820DW
WEL-TRY-LC215XLM	LC215XLM	M			
WEL-TRY-LC215XLY	LC215XLY	Y			
WEL-TRY-LC213BK	LC213BK	K			
WEL-TRY-LC213C	LC213C	C			
WEL-TRY-LC213M	LC213M	M			
WEL-TRY-LC213Y	LC213Y	Y			
WEL-TRY-LC211BK	LC211BK			K	Brother DCP-J963N-W/B/DCP-J962N/DCP-J968N-B Brother DCP-J762N/J562N Brother MFC-J880N/J730DW/J830DW/J900DW/ J990DW/J968N-W Brother DCP-J968N-W/B/J767N/J567N Brother MFC-J887N
WEL-TRY-LC211C	LC211C			C	Brother MFC-J837DN/DWN Brother MFC-J907DN/DWN Brother MFC-J997DN/DWN Brother MFC-J737DN/DWN
WEL-TRY-LC211M	LC211M			M	
WEL-TRY-LC211Y	LC211Y			Y	
WEL-TRY-LC669XLBK	LC669XLBK		K	Brother MFC-J2320 Brother MFC-J2720 (HK)	
WEL-TRY-LC665XLC	LC665XLC	C			
WEL-TRY-LC665XLM	LC665XLM	M			
WEL-TRY-LC665XLY	LC665XLY	Y			
WEL-TRY-LC663BK	LC663BK	K			
WEL-TRY-LC663C	LC663C	C			
WEL-TRY-LC663M	LC663M	M			

WEL-TRY-LC663Y	LC663Y	AP	Y	Brother DCP-J562DW/MFC-J480DW/MFC-J680DW/MFC-J880DW
WEL-TRY-LC261BK	LC261BK		K	
WEL-TRY-LC261C	LC261C		C	
WEL-TRY-LC261M	LC261M		M	
WEL-TRY-LC261Y	LC261Y		Y	
WEL-TRY-LC263BK	LC263BK		K	
WEL-TRY-LC263C	LC263C		C	
WEL-TRY-LC263M	LC263M		M	
WEL-TRY-LC263Y	LC263Y		Y	
WEL-TRY-LC239XLBK	LC239XLBK	AUS	K	Brother MFC-J5320 Brother MFC-J5720
WEL-TRY-LC237XLBK	LC237XLBK		K	Brother MFC-J4120 Brother MFC-J4620
WEL-TRY-LC235XLC	LC235XLC		C	Brother MFC-J5720 Brother MFC-J4120 Brother MFC-J4620 Brother MFC-J5320 Brother DCP-J562DW/MFC-J480DW/MFC-J680DW/MFC-J880DW (Only for use in LC233/LC231)
WEL-TRY-LC235XLM	LC235XLM		M	
WEL-TRY-LC235XLY	LC235XLY		Y	
WEL-TRY-LC233BK	LC233BK		K	
WEL-TRY-LC233C	LC233C		C	
WEL-TRY-LC233M	LC233M		M	
WEL-TRY-LC233Y	LC233Y		Y	
WEL-TRY-LC231BK	LC231BK		K	
WEL-TRY-LC231C	LC231C		C	
WEL-TRY-LC231M	LC231M		M	
WEL-TRY-LC231Y	LC231Y		Y	
WEL-TRY-LC679XLBK	LC679XLBK		SA	
WEL-TRY-LC675XLC	LC675XLC	C		
WEL-TRY-LC675XLM	LC675XLM	M		
WEL-TRY-LC675XLY	LC675XLY	Y		
WEL-TRY-LC673BK	LC673BK	K		
WEL-TRY-LC673C	LC673C	C		
WEL-TRY-LC673M	LC673M	M		
WEL-TRY-LC673Y	LC673Y	Y		
WEL-TRY-LC20EBK	LC20EBK	USA	K	Brother MFC-J5920DW Brother MFC-J985DW/J985DWXL
WEL-TRY-LC20EC	LC20EC		C	
WEL-TRY-LC20EM	LC20EM		M	
WEL-TRY-LC20EY	LC20EY		Y	
WEL-TRY-LC21EBK	LC21EBK	JPN	K	Brother DCP-J983N
WEL-TRY-LC21EC	LC21EC		C	
WEL-TRY-LC21EM	LC21EM		M	
WEL-TRY-LC21EY	LC21EY		Y	
WEL-TRY-LC22EBK	LC22EBK	EUR	K	Brother MFC-J5920DW
WEL-TRY-LC22EC	LC22EC		C	
WEL-TRY-LC22EM	LC22EM		M	
WEL-TRY-LC22EY	LC22EY		Y	
WEL-TRY-LC22UBK	LC22UBK	EUR	K	Brother MFC-J985DW/DCP-J785DW
WEL-TRY-LC22UC	LC22UC		C	
WEL-TRY-LC22UM	LC22UM		M	

WEL-TRY-LC22UY	LC22UY	AU	Y	Brother MFC-J5920DW
WEL-TRY-LC23EBK	LC23EBK		K	
WEL-TRY-LC23EC	LC23EC		C	
WEL-TRY-LC23EM	LC23EM		M	
WEL-TRY-LC23EY	LC23EY		Y	




WEL-TRY For Brother III Series Cartridge 为彩兄弟三代产品

Product Code	OEM Product Code	Region	Color	Description
WEL-TRY-LC3029BK	LC3029BK	USA	K	Brother MFC-J5830DW Brother MFC-J5830DW XL Brother MFC-J6535DW Brother MFC-J6535DW XL
WEL-TRY-LC3029C	LC3029C		C	
WEL-TRY-LC3029M	LC3029M		M	
WEL-TRY-LC3029Y	LC3029Y		Y	
WEL-TRY-LC3017BK	LC3017BK		K	Brother MFC-J5330DW Brother MFC-J6530DW Brother MFC-J6930DW Brother MFC-J6730DW
WEL-TRY-LC3017C	LC3017C		C	
WEL-TRY-LC3017M	LC3017M		M	
WEL-TRY-LC3017Y	LC3017Y		Y	
WEL-TRY-LC3019BK	LC3019BK		K	
WEL-TRY-LC3019C	LC3019C		C	
WEL-TRY-LC3019M	LC3019M		M	
WEL-TRY-LC3019Y	LC3019Y		Y	

WEL-TRY-LC3217BK	LC3217BK	EUR	K	Brother MFC-J5330DW Brother MFC-J5335DW Brother MFC-J5730DW Brother MFC-J5930DW Brother MFC-J6530DW Brother MFC-J6930DW Brother MFC-J6935DW
WEL-TRY-LC3217C	LC3217C		C	
WEL-TRY-LC3217M	LC3217M		M	
WEL-TRY-LC3217Y	LC3217Y		Y	
WEL-TRY-LC3219BK	LC3219BK		K	
WEL-TRY-LC3219C	LC3219C		C	
WEL-TRY-LC3219M	LC3219M		M	
WEL-TRY-LC3219Y	LC3219Y		Y	
WEL-TRY-LC3317BK	LC3317BK	AUS	K	Brother MFC-J5330DW Brother MFC-J5335DW Brother MFC-J5730DW Brother MFC-J5930DW Brother MFC-J6530DW Brother MFC-J6930DW Brother MFC-J6935DW
WEL-TRY-LC3317C	LC3317C		C	
WEL-TRY-LC3317M	LC3317M		M	
WEL-TRY-LC3317Y	LC3317Y		Y	
WEL-TRY-LC3319BK	LC3319BK		K	
WEL-TRY-LC3319C	LC3319C		C	
WEL-TRY-LC3319M	LC3319M		M	
WEL-TRY-LC3319Y	LC3319Y		Y	
WEL-TRY-LC3329BK	LC3329BK		K	Brother MFC-J5930DW Brother MFC-J6935DW
WEL-TRY-LC3329C	LC3329C		C	
WEL-TRY-LC3329M	LC3329M		M	
WEL-TRY-LC3329Y	LC3329Y		Y	
WEL-TRY-LC3129BK	LC3129BK		K	Brother MFC-J6995CDW
WEL-TRY-LC3129C	LC3129C		C	
WEL-TRY-LC3129M	LC3129M		M	
WEL-TRY-LC3129Y	LC3129Y		Y	
WEL-TRY-LC3117BK	LC3117BK	JPN	K	Brother MFC-J6980CDW Brother MFC-J6580CDW Brother MFC-J6583CDW Brother MFC-J6983CDW Brother MFC-J5630CDW
WEL-TRY-LC3117C	LC3117C		C	
WEL-TRY-LC3117M	LC3117M		M	
WEL-TRY-LC3117Y	LC3117Y		Y	
WEL-TRY-LC3119BK	LC3119BK		K	
WEL-TRY-LC3119C	LC3119C		C	
WEL-TRY-LC3119M	LC3119M		M	
WEL-TRY-LC3119Y	LC3119Y		Y	
WEL-TRY-LC3617BK	LC3617BK	AP	K	Brother MFC-J2330DW Brother MFC-J2730DW Brother MFC-J3530DW Brother MFCJ-3930DW
WEL-TRY-LC3617C	LC3617C		C	
WEL-TRY-LC3617M	LC3617M		M	
WEL-TRY-LC3617Y	LC3617Y		Y	
WEL-TRY-LC3619BK	LC3619BK		K	
WEL-TRY-LC3619C	LC3619C		C	
WEL-TRY-LC3619M	LC3619M		M	
WEL-TRY-LC3619Y	LC3619Y		Y	
WEL-TRY-LC3717BK	LC3717BK	ME	K	Brother MFC-J2330DW Brother MFC-J3930DW
WEL-TRY-LC3717C	LC3717C		C	
WEL-TRY-LC3717M	LC3717M		M	
WEL-TRY-LC3717Y	LC3717Y		Y	
WEL-TRY-LC3719BK	LC3719BK		K	
WEL-TRY-LC3719C	LC3719C		C	
WEL-TRY-LC3719M	LC3719M		M	
WEL-TRY-LC3719Y	LC3719Y		Y	

WEL-TRY-LC3111BK	LC3111BK	JPN	K	Brother DCP-J972N/DCP-J973N-W/B Brother DCP-J978N/DCP-J572N Brother DCP-J577N/MFC-J893N Brother MFC-J898N/MFC-J998DN/DWN Brother MFC-J738DN/DCP-J982N-B/W Brother DCP-J582N/MFC-J903N
WEL-TRY-LC3111C	LC3111C		C	
WEL-TRY-LC3111M	LC3111M		M	
WEL-TRY-LC3111Y	LC3111Y		Y	
WEL-TRY-LC3213BK	LC3213BK	EUR	K	Brother MFC-J890DW/J895DW Brother DCP-J772DW/J774DW Brother DCP-J572DW Brother MFC-J491DW/J497DW
WEL-TRY-LC3213C	LC3213C		C	
WEL-TRY-LC3213M	LC3213M		M	
WEL-TRY-LC3213Y	LC3213Y		Y	
WEL-TRY-LC3211BK	LC3211BK		K	
WEL-TRY-LC3211C	LC3211C		C	
WEL-TRY-LC3211M	LC3211M		M	
WEL-TRY-LC3211Y	LC3211Y		Y	
WEL-TRY-LC3011BK	LC3011BK		USA	
WEL-TRY-LC3011C	LC3011C	C		
WEL-TRY-LC3011M	LC3011M	M		
WEL-TRY-LC3011Y	LC3011Y	Y		
WEL-TRY-LC3013BK	LC3013BK	K		
WEL-TRY-LC3013C	LC3013C	C		
WEL-TRY-LC3013M	LC3013M	M		
WEL-TRY-LC3013Y	LC3013Y	Y		
WEL-TRY-LC3311BK	LC3311BK	AUS		K
WEL-TRY-LC3311C	LC3311C		C	
WEL-TRY-LC3311M	LC3311M		M	
WEL-TRY-LC3311Y	LC3311Y		Y	
WEL-TRY-LC3313BK	LC3313BK		K	
WEL-TRY-LC3313C	LC3313C		C	
WEL-TRY-LC3313M	LC3313M		M	
WEL-TRY-LC3313Y	LC3313Y		Y	
WEL-TRY-LC3511k	LC3511k			K
WEL-TRY-LC3511C	LC3511C	C		

WEL-TRY-LC3511M	LC3511M	AP	M	Brother MFC-J690DW Brother MFC-J890DW Brother DCP-J572DW Brother MFC-J491DW
WEL-TRY-LC3511Y	LC3511Y		Y	
WEL-TRY-LC3513k	LC3513k		K	
WEL-TRY-LC3513C	LC3513C		C	
WEL-TRY-LC3513M	LC3513M		M	
WEL-TRY-LC3513Y	LC3513Y		Y	



WEL-TRY For Brother IV Series Cartridge为彩兄弟4代产品

Product Code	OEM Product Code	Region	Color	Description
WEL-TRY-LC3033BK	LC3033BK	USA	K	Brother MFC-J995DW Brother MFC-J815DW Brother MFC-J805DW/XLDW
WEL-TRY-LC3033C	LC3033C		C	
WEL-TRY-LC3033M	LC3033M		M	
WEL-TRY-LC3033Y	LC3033Y		Y	
WEL-TRY-LC3035BK	LC3035BK		K	
WEL-TRY-LC3035C	LC3035C		C	
WEL-TRY-LC3035M	LC3035M		M	
WEL-TRY-LC3035Y	LC3035Y		Y	
WEL-TRY-LC3037BK	LC3037BK		K	
WEL-TRY-LC3037C	LC3037C		C	
WEL-TRY-LC3037M	LC3037M		M	
WEL-TRY-LC3037Y	LC3037Y		Y	
WEL-TRY-LC3039BK	LC3039BK		K	

WEL-TRY-LC3039C	LC3039C		C	
WEL-TRY-LC3039M	LC3039M		M	
WEL-TRY-LC3039Y	LC3039Y		Y	
WEL-TRY-LC3133BK	LC3133BK	JPN	K	Brother MFC-J1500N Brother DCP-J988N Brother MFC-J1605DN
WEL-TRY-LC3133C	LC3133C		C	
WEL-TRY-LC3133M	LC3133M		M	
WEL-TRY-LC3133Y	LC3133Y		Y	
WEL-TRY-LC3135BK	LC3135BK		K	
WEL-TRY-LC3135C	LC3135C		C	
WEL-TRY-LC3135M	LC3135M		M	
WEL-TRY-LC3135Y	LC3135Y		Y	
WEL-TRY-LC3139BK	LC3139BK		K	
WEL-TRY-LC3139C	LC3139C		C	
WEL-TRY-LC3139M	LC3139M		M	
WEL-TRY-LC3139Y	LC3139Y		Y	
WEL-TRY-LC3233BK	LC3233BK	EUR	K	Brother DCP-J1100DW Brother MFC-J1300
WEL-TRY-LC3233C	LC3233C		C	
WEL-TRY-LC3233M	LC3233M		M	
WEL-TRY-LC3233Y	LC3233Y		Y	
WEL-TRY-LC3235BK	LC3235BK		K	
WEL-TRY-LC3235C	LC3235C		C	
WEL-TRY-LC3235M	LC3235M		M	
WEL-TRY-LC3235Y	LC3235Y		Y	
WEL-TRY-LC3237BK	LC3237BK		K	
WEL-TRY-LC3237C	LC3237C		C	
WEL-TRY-LC3237M	LC3237M		M	
WEL-TRY-LC3237Y	LC3237Y		Y	
WEL-TRY-LC3239BK	LC3239BK	K		
WEL-TRY-LC3239C	LC3239C	C		
WEL-TRY-LC3239M	LC3239M	M		
WEL-TRY-LC3239Y	LC3239Y	Y		
WEL-TRY-LC3333BK	LC3333BK	AUS	K	Brother DCP-J1100DW Brother MFC-J1300
WEL-TRY-LC3333C	LC3333C		C	
WEL-TRY-LC3333M	LC3333M		M	
WEL-TRY-LC3333Y	LC3333Y		Y	
WEL-TRY-LC3337BK	LC3337BK		K	Brother MFC-J6945DW Brother MFC-J5945DW Brother MFC-J5845DW Brother MFC-J6545DW
WEL-TRY-LC3337C	LC3337C		C	
WEL-TRY-LC3337M	LC3337M		M	
WEL-TRY-LC3337Y	LC3337Y		Y	
WEL-TRY-LC3339BK	LC3339BK		K	
WEL-TRY-LC3339C	LC3339C		C	
WEL-TRY-LC3339M	LC3339M		M	
WEL-TRY-LC3339Y	LC3339Y		Y	



WEL-TRY For Brother V Series Cartridge为彩兄弟5代产品

兄弟五代

对应本厂模具WEL-TRY	地区AREA	为彩型号	原装型号OEM MODEL	打印机PRINTER
对应本厂兄弟LC492	欧洲/EUROPE	WT-LC421XL-BK	LC421XL-BK	DCP-J1050DW MFC-J1010DW DCP-J1140DW
		WT-LC421XL-C	LC421XL-C	
		WT-LC421XL-M	LC421XL-M	
		WT-LC421XL-Y	LC421XL-Y	
		WT-LC422-BK	LC422-BK	MFC-J5340DW/ MFC-J5345DW/ MFC-J5740DW/ MFC-J6540DW/ MFC-J6940DW
		WT-LC422-C	LC422-C	
		WT-LC422-M	LC422-M	
		WT-LC422-Y	LC422-Y	
		WT-LC422XL-BK	LC422XL-BK	
		WT-LC422XL-C	LC422XL-C	
		WT-LC422XL-M	LC422XL-M	
		WT-LC422XL-Y	LC422XL-Y	

对应本厂模具WEL-TRY	地区AREA	为彩型号	原装型号OEM MODEL	打印机PRINTER	
对应本厂兄弟四代	欧洲/EUROPE	WT-LC424-BK	LC424-BK	DPC-J1200DW	
		WT-LC424-C	LC424-C		
		WT-LC424-M	LC424-M		
		WT-LC424-Y	LC424-Y		
		WT-LC426-BK	LC426-BK	MFC-J4335DW MFC-J4340DW MFC-J4535DW MFC-J4540DW	
		WT-LC426-C	LC426-C		
		WT-LC426-M	LC426-M		
		WT-LC426-Y	LC426-Y		
		WT-LC426XL-BK	LC426XL-BK		
		WT-LC426XL-C	LC426XL-C		
		WT-LC426XL-M	LC426XL-M		
		WT-LC426XL-Y	LC426XL-Y		
		WT-LC427-BK	LC427-BK		HL-J6010DW/ MFC-J5955DW/ MFC-J6955DW/ MFC-J6957DW/ MFC-J6959DW
		WT-LC427-C	LC427-C		
		WT-LC427-M	LC426-M		
		WT-LC427-Y	LC426-Y		
		WT-LC427XL-BK	LC427XL-BK		
		WT-LC427XL-C	LC427XL-C		
		WT-LC427XL-M	LC427XL-M		
		WT-LC427XL-Y	LC427XL-Y		

对应本厂模具WEL-TRY MOLD	地区AREA	为彩型号 WEL-TRY MODEL	原装型号OEM MODEL	打印机PRINTER
对应本厂兄弟LC492	北美/north america	WT-LC401-BK	LC401-BK	MFC-J1010DW/ MFC-J1012DW/ MFC-J1170DW
		WT-LC401-C	LC401-C	
		WT-LC401-M	LC401-M	
		WT-LC401-Y	LC401-Y	
		WT-LC401XL-BK	LC401XL-BK	
		WT-LC401XL-C	LC401XL-C	
		WT-LC401XL-M	LC401XL-M	
		WT-LC401XL-Y	LC401XL-Y	
	北美/南美/south america/north america	WT-LC402-BK	LC402-BK	MFC-J5340DW/ MFC-J6740DW/ MFC-J6540DW/ MFC-J6940DW
		WT-LC402-C	LC402-C	
		WT-LC402-M	LC402-M	
		WT-LC402-Y	LC402-Y	
		WT-LC402XL-BK	LC402XL-BK	
		WT-LC402XL-C	LC402XL-C	
		WT-LC402XL-M	LC402XL-M	
WT-LC402XL-Y		LC402XL-Y		
对应本厂模具WEL-TRY MOLD	地区AREA	为彩型号 WEL-TRY MODEL	原装型号OEM MODEL	打印机PRINTER
		WT-LC404-BK	LC404-BK	MFC-J1205DW/ MFC-J1215DW
		WT-LC404-C	LC404-C	
		WT-LC404-M	LC404-M	
		WT-LC404-Y	LC404-Y	

对应本厂兄弟四代	北美/north america	WT-LC406-BK	LC406-BK	MFC-J4335DW/ MFC-J4345DW/ MFC-J4535DW/ MFC-J5855DW/ MFC-J5955DW/ MFC-J6555DW/ MFC-J6955DW
		WT-LC406-C	LC406-C	
		WT-LC406-M	LC406-M	
		WT-LC406-Y	LC406-Y	
		WT-LC406XL-BK	LC406XL-BK	
		WT-LC406XL-C	LC406XL-C	
		WT-LC406XL-M	LC406XL-M	
		WT-LC406XL-Y	LC406XL-Y	
对应本厂模具WEL-TRY MOLD	地区AREA	为彩型号 WEL-TRY MODEL	原装型号OEM MODEL	打印机PRINTER
对应本厂兄弟LC492	东欧/东南亚Eastern europe/southeast Asia	WT-LC462-BK	LC462-BK	MFC-J2340DW/ MFC-J3540DW/ MFC-J3940DW
		WT-LC462-C	LC462-C	
		WT-LC462-M	LC462-M	
		WT-LC462-Y	LC462-Y	
		WT-LC462XL-BK	LC462XL-BK	
		WT-LC462XL-C	LC462XL-C	
		WT-LC462XL-M	LC462XL-M	
		WT-LC462XL-Y	LC462XL-Y	
	中东/南非Middle east/south africa	WT-LC472XL-BK	LC472XL-BK	
		WT-LC472XL-C	LC472XL-C	
		WT-LC472XL-M	LC472XL-M	
		WT-LC472XL-Y	LC472XL-Y	

对应本厂模具WEL-TRY MOLD	地区AREA	为彩型号 WEL-TRY MODEL	原装型号OEM MODEL	打印机PRINTER
对应本厂兄弟LC3111	日本/japan	WT-LC411-BK	LC411-BK	DCP-J526N DCP-J914N/ DCP-J926N-W/B/MFC-J904N/ MFC-J739DN/DWN/ MFC-J939DN/DWN DCP-J1800N
		WT-LC411-C	LC411-C	
		WT-LC411-M	LC411-M	
		WT-LC411-Y	LC411-Y	
		WT-LC412-BK	LC412-BK	MFC-J7100CDW/ MFC-J7300CDW
		WT-LC412-C	LC412-C	
		WT-LC412-M	LC412-M	
		WT-LC412-Y	LC412-Y	
WT-LC412XL-BK	LC412XL-BK			
WT-LC412XL-C	LC412XL-C			
WT-LC412XL-M	LC412XL-M			
WT-LC412XL-Y	LC412XL-Y			
对应本厂LC492				
对应本厂模具WEL-TRY MOLD	地区AREA	为彩型号 WEL-TRY MODEL	原装型号OEM MODEL	打印机PRINTER
对应本厂兄弟四代	日本/japan	WT-LC414-BK	LC414-BK	DCP-J1200N
		WT-LC414-C	LC414-C	
		WT-LC414-M	LC414-M	
		WT-LC414-Y	LC414-Y	
		WT-LC416XL-BK	LC416XL-BK	DCP-J4140N/ MFC-J4440N/ MFC-J4540N MFC-J4940DN
		WT-LC416XL-C	LC416XL-C	
		WT-LC416XL-M	LC416XL-M	
		WT-LC416XL-Y	LC416XL-Y	
		WT-LC417XL-BK	LC417XL-BK	

		WT-LC417XL-C	LC417XL-C	HL-J7010CDW/ MFC-J5800CDW/ MFC-J7500CDW/ MFC-J7600CDW
		WT-LC417XL-M	LC417XL-M	
		WT-LC417XL-Y	LC417XL-Y	
对应本厂模具WEL-TRY MOLD	地区AREA	为彩型号WEL-TRY MODEL	原装型号OEM MODEL	打印机PRINTER
对应本厂兄弟LC492	大洋洲/oceania	WT-LC431XL-BK	LC431XL-BK	DCP-J1050DW/ DCP-J1140DW/ MFC-J1010DW
		WT-LC431XL-C	LC431XL-C	
		WT-LC431XL-M	LC431XL-M	
		WT-LC431XL-Y	LC431XL-Y	
		WT-LC432-BK	LC432-BK	MFC-J5340DW/ MFC-J5740DW/ MFC-J6540DW/ MFC-J6740DW/ MFC-J6940DW
		WT-LC432-C	LC432-C	
		WT-LC432-M	LC432-M	
		WT-LC432-Y	LC432-Y	
		WT-LC432XL-BK	LC432XL-BK	
		WT-LC432XL-C	LC432XL-C	
		WT-LC432XL-M	LC432XL-M	
		WT-LC432XL-Y	LC432XL-Y	
		WT-LC434-BK	LC434-BK	
WT-LC434-C	LC434-C			
WT-LC434-M	LC434-M			
WT-LC434-Y	LC434-Y			
对应本厂模具WEL-TRY MOLD	地区AREA	为彩型号WEL-TRY MODEL	原装型号OEM MODEL	打印机PRINTER
		WT-LC434-BK	LC434-BK	DCP-J1200W
		WT-LC434-C	LC434-C	
		WT-LC434-M	LC434-M	
		WT-LC434-Y	LC434-Y	

对应本厂兄弟四代

大洋洲/oceania	WT-LC436XL-BK	LC436XL-BK	MFC-J4340DW/ MFC-J4440DW/ MFC-J4540DW/ MFC-J5855DW/ MFC-J5955DW/ MFC-J6555DW/ MFC-J6955DW/ MFC-J6957DW
	WT-LC436XL-C	LC436XL-C	
	WT-LC436XL-M	LC436XL-M	
	WT-LC436XL-Y	LC436XL-Y	
东南亚southeast Asia	WT-LC456XL-BK	LC456XL-BK	MFC-J4340DW/ MFC-J4540DW
	WT-LC456XL-C	LC456XL-C	
	WT-LC456XL-M	LC456XL-M	
	WT-LC456XL-Y	LC456XL-Y	



